SERVICE PARTS LIST


Milwankee.® SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS REVISED BULLETIN DATE Jan. 2002 MAG STAND CONTROL PANEL WIRING INSTRUCTION SERIAL CATALOGNO. 23-35-0360 **SEE BELOW** NUMBER

Component Parts (Small #) Are Included When NO. REQ. **DESCRIPTION OF PART** FIG. PART NO. Ordering The Assembly (Large #). 06-81-8650 6-32 x 1/4" Rd. Hd. Sems 8 06-82-7252 8-32 x 3/8" Pan Hd. Slt. Tapt. T-20 9 4 SEE REVERSE SIDE BEFORE WIRING FOR IMPORTANT NOTES AND IMPORTANT! 06-95-5150 Sems Machine Ground Screw 13 Remove the film 22-64-3285 Power Cord Assembly 17 (24) from the back of Control Panel Assembly 18 23-35-0360 the terminal 28-50-0600 Mag Stand Housing 21 OPERATIONAL CHECK PROCEDURE pad prior to 24 22-64-3290 Motor Cord Assembly assembly 33 Electromagnetic Base 44-26-0070 See note 2. 23-66-2265 Drill Switch Assembly 38 39 23-66-2260 Magnet Switch Potted PCB Kit 40 14-46-2040 BLACK (38) 9 YELLOW (39) BLUE(12) (17) (15)WHITE Insert black wire #4 into wire trap. See note 3 (11)BROWN 9 40 Route two magnetic base leads (brown wires #10 and 11) **BACK VIEW OF PANEL** through the opening in the bottom of the mag stand housing #21. 4 BLACK (14) **(15)**WHITE Route wire #14

Secure the cord #24 from drill in the top opening of the mag stand housing. The cord jacket is to extend .25 minimum beyond the fittings.

EXAMPLE:

- Secure the power cord assembly #17 to the control panel kit #18. The cord jacket is to extend .25 minimum beyond the fittings.
- Attach ground terminals from green wires #3 and #6 to mag stand housing with ground screws #13. Orient the terminals as shown.
- Orient terminal pad (component of the potted pcb kit), as shown. Remove film from the back of the terminal pad and secure to mag stand housing with screw #8.
- Attach the leads from the magnetic base, as shown. Note: the leads from the magnetic base are intrerchangeable and can be attached to the panel in either location.
- Route black wire #4 from the power cord assembly into the wire trap on the potted pcb kit, as shown.
- Connect all wires, as shown. In assembly, wires #5, #6, #10 and #11 must be contained beneath the electronics boat.
- Align the potted boat with the groove in the mag stand housing cavity. Gently push the bundle of wires and the control panel assembly into the housing. Avoid pinching wires as the control panel is being installed.



ATTENTION Observe precautions for handling electrostatic sensitive devices

TERMINAL DESCRIPTION		
Code	Part No.	Qnty.
T1	23-74-0895	2
T2	23-74-0440	4
T3	23-74-0430	6
T4		2