



## Parts List for 1320-98 Type 5

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	000000-00	No Longer Available	1
3	400322-71SV	FIELD	1
4	012158-00	SCREW	2
5	144111-03	NAMEPLATE	1
6	014437-00	SCREW	2
7	133410-00	FAN	1
8	051404-03	COVER	1
9	143691-00	GASKET	1
10	135937-00	BEARING,ROLLER	1
11	700964-00	BEARING,BALL	2
12	021246-00	NEEDLE BEARING	4
13	051403-06SV	GEAR CASE	1
14	400147-00	GEAR	1
15	007027-00	KEY	1
16	133316-00	SPINDLE	1
17	099022-02	RET RING	1
18	450819-00	WASHER	1
19	400814-00	BRUSH & SPRING	2
20	000376-00	SCREW	2
21	400718-00	NYLON BALL	2
22	046210-00	BRUSH CAP	2
23	61208-03	HOLDER,BRUSH	2
24	068470-00	TERMINAL	2
25	330003-04	BEARING,BALL	1
26	132332-00	SLEEVE	1
27	033874-00	SCREW	2

## Parts List for 1320-98 Type 5

Item Number	Part Number	Description	Qty Required
28	21235-00	COVER	1
29	700735-00	PIN	1
30	51407-00	WASHER	4
31	051405-00SV	GEAR ASSY	1
32	049082-00	GEAR	1
33	051401-00	PINION	1
34	051406-00SV	GEAR	1
35	021822-00	GEAR	1
36	051402-00	PINION	1
40	099447-20	SCREW	2
41	099447-40	SCREW	2
42	444362-00	TERMINAL	2
800	429698-00	GREASE:4 LB CAN	1