



## Parts List for 690LRP Type 1

Item Number	Part Number	Description	Qty Required
1	903660	ARMATURE	1
2	904509SV	FIELD	1
3	N030459	BRUSH & SPRING	2
4	A22756	SWITCH	1
5	839549	CORD	1
6	152684-00	TERMINAL	1
7	697861	TERMINAL,GROUND	1
11	855284	BEARING	1
21	874299	FAN	1
22	803483	BRUSH CAP	2
23	873497	BRUSH HOLDER	2
24	878064SV	BEARING	1
25	A19609	REAR HOUSING	1
26	905489	HOUSING CAP	1
27	876671	COLLET 1/2 INCH	1
27	876669	COLLET 1/4 INCH	1
27	42975	3/8 INCH COLLET ASSY	1
27	42999	1/4 INCH COLLET ASSY	1
27	42950	1/2 INCH COLLET ASSY	1
52	A11034	FRONT CASE	1
81	875893	COLLET NUT	1
83	872793	CHUCK	1
98	823030	SNAP-RING	1
100	878389	SCREW	1
102	885267	O RING	1
103	803632	SET-SCREW	2
104	803496	WASHER	2

## Parts List for 690LRP Type 1

Item Number	Part Number	Description	Qty Required
105	898484	PLUG	1
106	876965	SCREW	2
108	802426	RING	1
110	901266	STRAIN RELIEVER	1
111	800835	PIN	4
113	682063	CONNECTOR VS	1
115	892780	SCREW	1
120	681260	SCREW & WASHER	2
121	874137	CORD CLAMP	1
122	878262	SCREW	1
123	887452	DUST SHIELD	1
223	872998	DEPTH RING	1
225	800995	BASE KNOB	1
226	802425	WASHER	1
229	802306	HEX HEAD SCREW	1
230	875807	SUB BASE	1
231	688860	SCREW	3
233	000000-00	No Longer Available	1
234	800869	SPRING	3
239	903118	PIN	1
240	903114	BUCKLE	1
241	903120	SHAFT	1
242	A00323	WEAR PLATE	1
243	802417	WASHER	1
244	903693	NUT	1
245	42160	ROUTER EDGE GUIDE	1
246	803160	SCREW	1

## Parts List for 690LRP Type 1

Item Number	Part Number	Description	Qty Required
247	882810	KNOB	1
248	824588	ROD GUIDE	1
249	000000-00	No Longer Available	1
249	902829	CARRYING CASE	1
251	A22709	OPEN-END WRENCH	1
252	A20145	NAMEPLATE	1
800	883807	GREASE	1