



Parts List for 7144 Type 4

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	142959-71	FIELD	1
3	140994-00	BRUSH	2
4	000000-00	No Longer Available	1
5	140998-00	HOLDER, BRUSH	2
6	000000-00	No Longer Available	1
7	90678-98	CORD/6FT./18-2	1
8	158478-00	SINK,HEAT	2
10	157315-00	WASHER,SPRING	1
11	037381-00	WASHER	1
13	000000-00	No Longer Available	1
14	000000-00	No Longer Available	1
15	000000-00	No Longer Available	1
16	000000-00	No Longer Available	1
18	234900-02	PLUG 120V 2WIRE	1
19	000000-00	No Longer Available	1
20	000000-00	No Longer Available	1
21	000903-00	BALL	2
23	330019-04	SCREW,PLASTITE	8
24	679303-00	CHUCK & KEY	1
26	233304-00	NAMEPLATE-SHEET	1
28	000000-00	No Longer Available	1
29	157312-00	SCREW,SPEC.,LH	1
80	065288-01	CH KEY HOLDER	1
81	330034-00	KEY,CHUCK	1
861	000000-00	No Longer Available	1