





Parts List for FS200SD Type 2

Item Number	Part Number	Description	Qty Required
1	490591-00	FENCE ASSEMBLY	1
2	488993-00	HEX HD SCREW	2
3	491549-00	TOOTH WASHER	2
4	491550-00	PAN HD SCR	1
7	489076-00	HANDLE	1
8	489077-00	HEX NUT	1
51	489081-00	RUBBER BUMPER	2
54	489078-00	TABLE INSERT	1
55	488974-00	PAN HEAD SCREW	6
56	489080-00	NUT	2
57	489082-00	FLAT HEAD SCREW	1
60	489083-00	TABLE	1
61	489084-00	FILL HD SCREW	1
62	489085-00	FILL HD SCREW	1
64	489053-00	SCALE	1
65	488837-00	WARNING LABEL	1
69	490417-00SV	MITER GAUGE ASSY	1
87	488848-00	CHEESE HEAD SCREW	1
88	488981-00	TOOTH WASHER	5
89	489091-00	SPRING CLIP	1
90	489092-00	BLOCK	1
91	000000-00	No Longer Available	3
94	488793-00	FLAT WASHER	1
96	489096-00	FLAT HD SCREW	9
97	489097-00	SLEEVE	1
99	90521028	NAME PLATE	1
101	489100-00	FIBER WASHER	1

Parts List for FS200SD Type 2

Item Number	Part Number	Description	Qty Required
102	489123-00	FLAT WASHER	5
103	489071-00	LEVER	1
104	489101-00	THREADED ROD	1
105	489322-00	HANDWHEEL	1
106	489102-00	FLAT HEAD SCREW	1
107	489103-00	HANDLE	1
108	490375-00	SCREW	1
109	000000-00	No Longer Available	1
110	1343758	KEY	1
111	490895-00	CIRCUIT BREAKER	1
112	489107-00	TOOTH WASHER	1
113	1313228	NUT	1
114	821057	PAN HEAD SCREW	8
115	490844-00	CLAMP	1
116	491429-00	SWITCH COVER	1
117	489110-00	RUBBER FOOT	4
118	90515441-02	BASE	1
119	000000-00	No Longer Available	4
120	489113-00	BASE PLATE	1
121	90515002	WARNING LABEL	1
131	489012-00	WRENCH	1
132	490025-00	PAN HEAD SCREW	2
135	489579-00	JUMPER WIRE	1
136	90514149	CORDSET	1
139	488979-00	WIRE NUT	1
240	90515243	WARNING LABEL	1
242	492604-00SV	GUARD ASSEMBLY	1

Parts List for FS200SD Type 2

Item Number	Part Number	Description	Qty Required
243	489121-00	HEX HEAD SCREW	1
244	489122-00	TOOTH WASHER	1
246	488994-00	TOOTH WASHER	5
247	489124-00	SPLITTER BRACKET	1
248	489125-00	SPLITTER BRACKET	1
254	489016-00	RUBBER BUMPER	1
259	489026-00	HEX NUT	1
264	489127-00	WING NUT	1
270	489128-00	HEX HD SCREW	1
273	489126-00	HEX HEAD SCREW	2
297	489143-00	WASHER	1
298	489144-00	WASHER	1
299	488807-00	FLAT WASHER	3
300	90516316SV	MOTOR ASSEMBLY	1
302	90514148	MOTOR CORD	1
303	489132-00	SCREW	1
305	489587-00	STRAIN RELIEF	1
307	490336-00	END CAP	1
309	488916-00	BRUSH HOUSING	2
310	90512443	BRUSH	2
311	489138-00	PAN HEAD SCREW	3
312	488808-00	LOCK WASHER	9
313	488871-00	LOCK NUT	2
314	489591-00	MOTOR HOUSING	1
315	489141-00	WAVE WASHER	1
316	489142-00	BEARING	1
319	489159-00	BALL BEARING	1

Parts List for FS200SD Type 2

Item Number	Part Number	Description	Qty Required
320	098197-03	LOCK WASHER	3
321	330045-45	SCREW	3
323	562097-13	SCREW	2
324	489162-00	GEAR HOUSING	1
325	488957-00	BEARING ROLLER	1
326	492602-00	JACKSHAFT ASSEMBLY	1
328	489170-00	FLANGE	1
329	489171-00	ARBOR NUT	1
339	489172-00	SPRING PIN	2
340	489040-00	HEX FLANGE SCREW	3
341	489173-00	SCREW	1
343	488995-00	BRACKET ASSEMBLY	1
344	489174-00	SADDLE	1
345	489175-00	STRAP	6
346	000000-00	No Longer Available	1
347	489030-00	FLANGE NUT	12
348	489177-00	HEX FLANGE SCREW	3
352	489048-00	HEX HEAD SCREW	2
354	489178-00	SPRING PIN	1
356	489179-00	FLAT WASHER	1
357	489190-00	BLOCK	1
358	489191-00	HEX NUT	1
359	489192-00	FIBER WASHER	1
360	489193-00	FLAT WASHER	1
361	489194-00	WAVE WASHER	1
362	489037-00	PLATE	1
364	491557-00	SCREW	2

Parts List for FS200SD Type 2

Item Number	Part Number	Description	Qty Required
370	489031-00	SPACER	1
377	491559-00	POINTER	1
381	000000-00	No Longer Available	1
386	489027-00	SPRING PIN	1
514	491437-00	DUST CHUTE	1
515	491438-00	DUST BAG	1
601	489058-00	HEX NUT	24
602	489059-00	FLAT WASHER	24
604	491553-00	SCREW	4
605	90517088	BRACKET	1
607	489063-00	FOOT	1
608	000000-00	No Longer Available	20
609	489199-00	LEG	2
611	90513851	LEG	2
612	90515873	WHEEL ASSY.	2
615	000000-00	No Longer Available	1
846	489057-00	HARDWARE BAG	1
856	000000-00	No Longer Available	1
856	6005818	BLADE	1