



Parts List for FSD142K-2 Type 3

Item Number	Part Number	Description	Qty Required
2	5101752-00	WASHER	1
3	419626-00	BEARING WASHER	1
4	311993-00	SCREW	4
5	486562-00	SCREW	1
6	330019-05	SCREW,PLASTITE	1
7	5100184-01	MOTOR & GEARBOX	1
8	5100117-00	SPRING	1
9	5100115-00	BIT RELEASE RING	1
10	497927-01	RETAINING CLIP	1
11	5100776-00	HUB CAP	1
12	000000-00	No Longer Available	1
13	5100110-00	TOP PLATE	1
14	000000-00	No Longer Available	1
15	5100111-00	ACTUATOR FWR/REV	1
16	000000-00	No Longer Available	1
17	000000-00	No Longer Available	1
18	000000-00	No Longer Available	1
20	5100976-00	TERMINAL BLOCK	1
22	5100101-03	ACTUATOR	1
23	5100153-00	SHIFTER WIRE	1
24	5100035-01	SPRING	2
846	5100977-00	HARDWARE BAG	1
861	000000-00	No Longer Available	1
866	FSB14	BATTERY	2
867	5102026-00	BATTERY CAP	2
871	5103069-09	CHARGER ASSY.	1
875	5100785-00	LATCH	2