



Parts List for GSH500 Type 1

Item Number	Part Number	Description	Qty Required
1	464224-02	SWITCH	1
6	330013-02	SCREW,PLASTIC	5
9	380087-00	HANDLE,AUXILLRY	1
10	380503-00	SCREW	1
11	090914-00	WING NUT	1
17	33314-00	CONNECTOR	2
18	243755-03	LOCK-OFF BUTTON	1