



Parts List for HS1012 Type 1

Item Number	Part Number	Description	Qty Required
1	394465-00	HOUSING & COVER	1
2	394262-00	COMP. SPRING	1
3	330019-04	SCREW,PLASTITE	20
4	394488-01	FIELD	1
5	90519152	ARMATURE&FIELD	1
6	394471-00	BAFFLE	1
7	380973-00	BEARING SUPPORT	1
8	387542-00	BRUSH	2
9	381817-01	BRUSH HOLDER	2
10	394261-00	LOCK BUTTON	1
11	158495-00	SCREW,TAPTITE	4
12	394260-00	ACTUATOR	1
13	157315-00	WASHER,SPRING	1
14	394263-00	SPRING	1
15	330019-09	SCREW	2
16	148902-00	WASHER,PLAIN	1
17	90541380	SWITCH	1
18	90519082	GEARCASE ASSY	1
19	394474-00	GEAR COVER	1
20	90514920	BLADE & GEAR	1
21	98022-20	SCREW	2
22	148641-00	NUT,LOCK	7
23	394476-00	SPACER	7
24	133952-00	WASHER	1
25	87486-00	CONTACT,TERM.	1
26	151625-00	BLADE,POLARIZED	1
27	137646-00	TERMINAL	2

Parts List for HS1012 Type 1

Item Number	Part Number	Description	Qty Required
28	394058-00	GUARD	1
29	395871-00	BAIL HANDLE	1
30	614569-00	NAME PLATE	1
31	395619-00	ID LABEL	1
32	000000-00	No Longer Available	1
33	148814-00	BEARING	1
34	98022-16	SCREW	5
35	621914-00	SHEATH	1
800	429698-00	GREASE:4 LB CAN	1