






120V 240V KR550RE KR600RE KR540CRE KR550CRE KR600CRE KR650CRF KR572



KR550RE KR550CRE KR540CRE
KR600RE KR600CRE KR650CRF KR572



Parts List for KR600CREB3 Type 2

Item Number	Part Number	Description	Qty Required
101	376912-41	FIELD	1
102	374239-05	ARMATURE	1
103	374190-06	CLAMSHELL,SET	1
104	374217-02	BRUSH & PCB	1
105	375127-03	SWITCH	1
106	374216-00	GEARCASE ASSY	1
107	374189-00	SELECTOR	1
108	892261-00	WASHER,THRUST	1
109	000000-00	No Longer Available	1
110	821986-00	SPRING	1
111	377645-00	SPINDLE&GR.ASSY	1
112	000000-00	No Longer Available	1
113	374193-00	BEARING	1
114	479902-00	KEYLESS CHUCK	1
115	000000-00	No Longer Available	1
116	886095-00	BEARING,BAL	1
119	808704-12	CORDSET	1
121	805434	SCREW, SPECIAL	1
122	914115	BRUSH HOLDER	2
123	875735	BRUSH HOLDER	2
123	572462-00	BRUSH BOX	2
125	570544-00	BRUSH & SPRING	2
126	374218-01	ACTUATOR	1
127	374188-00	ACTUATOR	1
128	000000-00	No Longer Available	1
129	000000-00	No Longer Available	1
132	770236-00	PROTECTOR,CORD	1

Parts List for KR600CREB3 Type 2

Item Number	Part Number	Description	Qty Required
133	809961-00	SCREW	9
134	374186-04	BRAND LABEL	1
135	807745	CAPACITOR	1
138	000000-00	No Longer Available	1
139	376552-03	CLAMP	1
140	813918	SCREW	1
141	372814-00	DEPTH STOP	1
145	821070	CORD CLAMP	1
146	821057-00	SCREW	2