



Parts List for MS700K Type 1

Item Number	Part Number	Description	Qty Required
1	576373-10	ARMATURE	1
2	576374-08	FIELD	1
3	915068	BRUSH & SPRING	2
4	875735	BRUSH HOLDER	2
5	578974-00	BRUSH BOX	2
6	579050-00	SWITCH	1
7	581389-00	LEADWIRE ASSY.	1
9	579209-00	CORDSET	1
10	329301-00	CLAMP,CORD	1
11	573148-00	SCREW	4
12	000000-00	No Longer Available	1
13	579063-00	REAR LEGS	1
14	579062-00	FRONT LEGS	1
15	579051-00	SEAL	1
16	000000-00	No Longer Available	1
17	5103541-00	SCREW	8
18	574853-06	BEARING	2
19	000000-00	No Longer Available	1
20	586405-00SV	WASHER	1
21	797190	SCREW	1
22	000000-00	No Longer Available	1
23	579104-00SV	LARGE PLATEN	1
24	579239-00	FINGER PLATEN	1
25	808765-00	SCREW	1
26	90558556	PAD TIP	1
27	377148-00	PAD TIP	1
28	579056-00	SHROUD	1

Parts List for MS700K Type 1

Item Number	Part Number	Description	Qty Required
29	000000-00	No Longer Available	1
30	370748	SCREW	4
33	581103-00	PLATEN	1
34	581104-00	ALLEN WRENCH	1
36	000000-00	No Longer Available	1
74	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	579193-00	ACCY PACK	1
861	000000-00	No Longer Available	1