



Parts List for TR165 Type 2

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------------|--------------|
| 1 | 000000-00 | No Longer Available | 1 |
| 3 | 000000-00 | No Longer Available | 1 |
| 4 | 000000-00 | No Longer Available | 1 |
| 5 | 000000-00 | No Longer Available | 1 |
| 6 | 747634-00 | SPRING,BRUSH | 2 |
| 7 | 152872-00 | HOLDER,BRUSH | 2 |
| 8 | 152916-00 | BRUSH | 2 |
| 9 | 330019-09 | SCREW | 2 |
| 10 | 389626-00 | RUBBER PLUG | 1 |
| 11 | 157315-00 | WASHER,SPRING | 1 |
| 12 | 037653-00 | RING, RETAINING | 1 |
| 13 | 854978-00 | WASHER,SHIM | 1 |
| 14 | 150844-01 | PAD | 2 |
| 14 | 148991-01 | CASE,GEAR | 1 |
| 15 | 000000-00 | No Longer Available | 1 |
| 16 | 383994-00 | SWITCH,ON/OFF | 1 |
| 18 | 680131-01 | RECEPTACLE | 1 |
| 19 | 87486-00 | CONTACT,TERM. | 1 |
| 23 | 90516433SV | GEAR ASSY | 1 |
| 24 | 000000-00 | No Longer Available | 1 |
| 25 | 603759-01 | BLADE ASSEMBLY | 1 |
| 26 | 071653-13 | SPACER | 2 |
| 27 | 071653-13 | SPACER | 1 |
| 28 | 381980-00 | NUT,STOP | 5 |
| 29 | 88782-00 | SCREW | 5 |
| 30 | 397589-00 | WASHER | 1 |
| 31 | 158495-00 | SCREW,TAPTITE | 4 |

Parts List for TR165 Type 2

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------------|--------------|
| 32 | 330019-04 | SCREW,PLASTITE | 7 |
| 33 | 000000-00 | No Longer Available | 1 |
| 34 | 133952-00 | WASHER | 1 |
| 35 | 330045-05 | LOCK SCREW | 3 |
| 36 | 000000-00 | No Longer Available | 1 |
| 37 | 330001-08 | BEARING,SLEEVE | 1 |
| 39 | 151625-00 | BLADE,POLARIZED | 1 |
| 40 | 000000-00 | No Longer Available | 1 |
| 846 | 679853-00 | BLADE SPACER KT | 1 |