



## Parts List for TV810K Type 2

Item Number	Part Number	Description	Qty Required
101	573562-01S	ARMATURE	1
102	576086-04SV	FIELD	1
103	578957-00	SWITCH (ON-OFF)	1
104	949646-01	BRUSH,CUTOFF	2
105	562226-30	CORDSET	1
110	930275-00	COVER,BEARING	1
111	573119-02	BEARING	1
112	401622-01	RETAINER,BRG	1
113	330003-03	BEARING,BALL	1
114	580583-00	PINION	1
115	945292-00	NUT	1
116	572166-01S	GEAR CASE ASSY.	1
118	562097-10	SCREW	4
119	401623-00	BAFFLE	1
123	403156-00	FLANGE	1
124	573119-01	BEARING	1
125	576155-00	SPINDLE	1
126	574119-00	GEARCASE COVER	1
127	393576-00	GUARD SPRING	1
128	574114-00	GUARD	1
129	605415-00	FLANGE	1
130	562160-00	SCREW	3
131	574823-00	FLANGE,INNER	1
132	574822-00	FLANGE,OUTER	1
133	149142-00	HANDLE,SIDE	1
134	000000-00	No Longer Available	1
136	395985-01S	BRUSH HLDR.ASSY	2

## Parts List for TV810K Type 2

Item Number	Part Number	Description	Qty Required
139	000000-00	No Longer Available	1
140	572170-00	BUTTON,LOCK ON	1
141	562204-00	SPRING	1
142	562097-00	SCREW	4
145	000000-00	No Longer Available	1
146	573058-00	CORD PROTECTOR	1
147	562160-01	SCREW	4
148	949638-01	PLUG,RUBBER	2
151	562097-05	SCREW	2
152	930103-00	CLAMP,CORD	1
156	393799-00	O-RING	1
157	574113-00	SPRING	1
158	580584-00	GEAR	1
816	000000-00	No Longer Available	1
821	000000-00	No Longer Available	1
826	576224-00	WARNING LABEL	1
856	000000-00	No Longer Available	1
861	000000-00	No Longer Available	1
900	574122-00	WRENCH	1