


TORQUE 15-25 IN-LBS

ATTACH SPEED CLIP
PRIOR TO ASSEMBLY
OF DEVICES
TO FACE PLATE

WIRING HARNESS PIN PLUG
TO BE SNAPPED INTO OPENING
INSIDE REAR COVER



Parts List for GBV5000 Type 0

Item Number	Part Number	Description	Qty Required
1	91895680	SCREW .250-20X.750 H	1
2	Z-GS-0795	TANK FUEL 7G SS	1
3	GS-0443	CAP FUEL TANK	1
4	000000-00	No Longer Available	1
5	000000-00	No Longer Available	1
6	GS-0077	COVER END BLANK	1
7	000000-00	No Longer Available	1
8	Z-A14582	HOSE FUEL	1
9	GS-0227	CLAMP FUEL .50	1
10	95829230	SCREW .313-18X1.50 H	1
11	000000-00	No Longer Available	1
12	GS-0117	LUG GROUND	1
13	95829230	SCREW .313-18X1.50 H	1
14	000000-00	No Longer Available	1
15	SS-12-CD	SCREW .313-18X.750 H	1
16	GS-0118	STRAP GROUND	1
17	N017772	LOCK WASHER	1
18	SSF-8150	NUT .312-18 UNC HEX	1
19	GS-0433	ISOLATOR	1
19	GS-0033	ISOLATOR VIBRATION 1	1
20	000000-00	No Longer Available	1
21	91895680	SCREW .250-20X.750 H	1
22	GS-0456	DRAIN COCK GBV5000	1
23	N103455	GROMMET	1
24	000000-00	No Longer Available	1
25	SSN-619	WASHER .375 SPRING L	1
26	5140125-93	SCREW	1

Parts List for GBV5000 Type 0

Item Number	Part Number	Description	Qty Required
27	000000-00	No Longer Available	1
27	D29822	KIT SERVICE FOCUS MO	1
28	GS-0110	BOLT STATOR THRU 130	1
29	000000-00	No Longer Available	1
29	D29822	KIT SERVICE FOCUS MO	1
30	330016-13	WASHER	1
31	SSF-576	NUT .313-24 HEX W/KE	1
32	GS-0091-1	BOLT ROTOR THRU 130L	1
33	GS-0681	BREAKER CIRCUIT	1
34	SSF-575	NUT .250-20 HEX W/KE	1
35	GS-0104	CAPACITOR 50 UF	1
36	SSF-553-1	SCREW #10-24X.563 TH	1
37	GS-0019	RECEPTACLE 120V 20A	1
38	GS-0021	RECEPTACLE 125V 30A	1
39	GS-0445	RECEPTACLE 4 PRONG T	1
40	D21508	BREAKER CIRCUIT	1
41	GS-0045	SWITCH FULL POWER	1
42	GS-0046	SWITCH OFF - ON / ST	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	000000-00	No Longer Available	1
856	GS-0862	O-RING ROTOR BEARING	1
856	GS-0082	DIODE DSA	1