



## Parts List for D26676-BR Type 1

Item Number	Part Number	Description	Qty Required
1	663234-00	SCREW	11
2	663235-00	HANDLE COVER	1
3	663236-00	SWITCH	1
4	663238-00	CORD PROTECTOR	1
5	N039167	CORDSET	1
6	663304-00	SCREW	2
7	663247-00	CORD CLAMP	1
8	663248-00	SCALE LABEL	1
9	663249-00	BOLT	1
10	663250-00	GRIP	1
11	663251-00	SCALE	1
12	663252-00	COVER	1
13	663253-00	WASHER	1
14	663254-00	LEAF SPRING	1
16	N039171	RATING PLATE	1
17	663264-00	REAR COVER	1
20	663267-00	SCREW	2
21	663268-00	WASHER	4
22	663269-00	COVER	1
25	N039175	HOUSING	1
26	663273-00	SPRING	1
27	663274-00	SCREW	1
28	N039178	FIELD	1
29	663277-00	TUBE	1
31	663278-00	SCREW	2
32	663279-00	BEARING CUP	1
33	663280-00	BALL BEARING	1

## Parts List for D26676-BR Type 1

Item Number	Part Number	Description	Qty Required
34	N039176	ARMATURE	1
35	N039179	BRUSH SET	1
36	663284-00	BRUSH HOLDER	2
37	663285-00	BALL BEARING	2
38	663286-00	BUNG	1
39	663287-00	FAN COVER	1
41	N039180	CUTTER ASSEMBLY	1
42	663295-00	SCREW	3
43	663296-00	CLAMP	1
44	663297-00	BALL BEARING	1
45	663298-00	BRACKET	1
46	663299-00	SCREW	6
47	663300-00	PULLEY	1
48	663301-00	PULLEY SHAFT	1
49	663302-00	DRIVE BELT	1
50	663303-00	BELT COVER	1
51	663304-00	SCREW	1
52	663305-00	COMPRESSION SPRING	1
53	663306-00	SEAL	1
59	663289-00	CUTTER BLOCK	1
60	663290-00	BLADE CLAMP	2
61	663291-00	BLADE	2
62	663292-00	ADJUSTER	2
63	663293-00	SCREW	4
64	663294-00	BOLT	6
65	663311-00	HOLDER	1
66	663312-00	SCREW	4

## Parts List for D26676-BR Type 1

Item Number	Part Number	Description	Qty Required
67	663313-00	WRENCH	1
68	663314-00	FENCE	1
69	663315-00	GAUGE	1