





Parts List for D55152 Type 2

Item Number	Part Number	Description	Qty Required
7	629436-00	NAMEPLATE	1
36	N000231	LABEL	1
37	5130054-00	DECAL	1
39	5130059-00	DECAL	1
40	627676-00	WARNING LABEL	1
41	N018445	WARNING LABEL	1
42	000000-00	No Longer Available	1
46	000000-00	No Longer Available	1
50	5133478-01	FRAME	1
51	5140038-46	ELBOW	2
52	5140038-48	HOSE CLAMP	2
53	5140057-27	AIR HOSE	1
54	5140028-15	POWER CABLE	1
55	629406-00	PRESSURE SWITCH	1
56	5140028-16	ELBOW	1
57	5140028-17	COMPRESSION RING	2
58	5140028-18	LOCKNUT	2
59	619295-00	AFTERCOOLER	1
60	5140057-28	UNLOADER TUBE	1
61	5140028-19	COMPASS	2
62	629409-00	COMPRESSION NUT	1
63	5140028-20	NIPPLE	1
64	5140028-14	SAFETY VALVE	1
65	629408-00	COMPRESSION RING	1
66	5140028-21	NIPPLE	1
67	5130033-00	COLD START VALVE	1
68	5140030-78	CHECK VALVE ASSY	1

Parts List for D55152 Type 2

Item Number	Part Number	Description	Qty Required
72	5140030-78	CHECK VALVE ASSY	1
73	5140038-49	DRAIN VALVE	1
74	5140028-27	SCREW	12
75	5134369-00	FOOT	4
76	5140028-28	SCREW,SELF-TAP.	4
77	5140028-29	BASE PLATE	1
78	5140028-30	GROMMET	1
79	5140038-51	MANIFOLD	1
80	5137078-00	PUMP/MOTOR ASSY.	1
81	5140028-60	NUT	4
82	5140038-44	PRESSURE GAUGE	2
83	5140057-29	QUICK COUPLER	2
84	5140038-50	FRONT PANEL	1
85	5140057-30	PLUG	2
201	5130077-00	BOLT	4
203	5140016-71	CYLINDER HEAD	1
204	5140019-80	FILTER	1
205	5130078-00	GASKET	1
206	5140016-72	VALVE PLATE	1
207	5140026-39	GASKET	1
208	5140016-73	VALVE BLADE	2
209	5140016-74	VALVE PLATE GASKET	1
210	5140016-95	CYLINDER	1
211	5130105-00	BOLT	2
212	5140016-75	SEAL	1
213	5130084-00	PISTON RING SET	1
214	5130085-00	PISTON	1

Parts List for D55152 Type 2

Item Number	Part Number	Description	Qty Required
215	5130086-00	PIN	1
216	5130087-00	RETAINING RING	2
217	5130102-00	PISTON ASSY.	1
218	5130088-00	CONNECTING ROD	1
219	5140016-76	CONDENSER	1
220	5140016-77	COVER	1
222	5140016-78	DIPSTICK	1
223	5140016-79	SCREW	4
224	5140016-80	COVER,MOTOR	1
225	5140016-81	O-RING	1
226	5140016-82	SCREW	1
227	5140016-83	COVER,SEAL	1
228	5140040-44	CASE ASSY	1
229	5130101-00	NUT	2
230	5134583-00	CIRCUIT BREAKER	1
231	5140016-86	CRANKSHAFT	1
232	5140016-87	BEARING	1
233	5140016-88	SEAL	1
234	000000-00	No Longer Available	1
235	000000-00	No Longer Available	1
236	5134652-00	BEARING	1
237	5134707-00	END COVER	1
238	5140016-91	SCREW	2
239	5130107-00	FAN	1
240	5140016-92	HOUSING	1
241	5130097-00	SCREW	2
243	5140016-94	SEAL KIT	1

Parts List for D55152 Type 2

Item Number	Part Number	Description	Qty Required
800	5130427-00	OIL	1
800	5130702-00	OIL	3