



Parts List for DC528 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|------------------|--------------|
| 1 | 5140061-05 | HANDLE ASSEMBLY | 1 |
| 2 | 5140060-17 | FLUORESCENT BULB | 1 |
| 3 | 5140027-35 | TOP HOUSING ASSY | 1 |
| 866 | DC9071 | BATTERY PACK | 1 |
| 866 | DC9091 | BATTERY PACK | 1 |
| 867 | 645221-00 | BATTERY CAP | 1 |
| 871 | 388683-12 | 1 HOUR CHARGER | 1 |