



Parts List for DC840KA-BR Type 2

Item Number	Part Number	Description	Qty Required
1	658395-01	CLAMSHELL	1
2	646693-01SV	NOSE CONE	1
3	608024-00SV	ANVIL ASSY.	1
4	642883-01	WASHER - URETHANE	1
7	038769-00	SPRING	1
8	N020802	DETENT PIN	1
9	099205-07	ROLL PIN	1
10	N040122SV	MECHANISM ASSY	1
11	646694-01SV	ARMATURE ASSEMBLY	1
12	N211574	MAGNET RING	1
13	640550-00	BRUSH HLDR/BRUSH ASY	1
13	640550-00	BRUSH HLDR/BRUSH ASY	1
14	640555-00	BRUSH HLDR/BRUSH ASY	1
14	640555-00	BRUSH HLDR/BRUSH ASY	1
15	N019949	VSR SWITCH (DC)	1
16	659201-00	FWD/REV BUTTON	1
17	642886-00	CONE	1
18	682211-00	SCREW,TORX	9
19	148354-03	BIT CLIP	1
20	000000-00	No Longer Available	1
21	646763-00	IDENT. LABEL	1
861	637475-00	LATCH ASSEMBLY	2
861	380865-02	KIT,HANDLE	1
861	652211-00	KITBOX	1
866	DC9071	BATTERY PACK	2
867	645221-00	BATTERY CAP	2
871	DW9116-BR	CHARGER	1