



Parts List for DCD708C2 Type 1

Item Number	Part Number	Description	Qty Required
1	N553813	HOUSING	1
2	N703439	TRANSMISSION ASSY	1
3	N563289	MOTOR & SWITCH ASSY.	1
4	N399342	FWD/REV BUTTON	1
5	N071836	ROLL PIN	1
6	N463678	SCREW,PLASTITE	8
7	N474504	SCREW	4
8	N014681	DETENT SPRING	2
10	N268241	BELT HOOK KIT	1
11	N042665	MACHINE SCREW	1
15	N592424	RATING LABEL	1
16	N611305	WARNING LABEL	1
862	N294699	SOFT BAG	1
866	DCB203	BATTERY PACK	1
871	DCB115	CHARGER	1