

Parts List for DCHT860M1 Type 1

Item Number	Part Number	Description	Qty Required
1	90604310	HOUSING ASSEMBLY	1
2	90604969	BATTERY HOUSING	1
3	90604970	BATTERY TOP	1
4	90603422	GEARCASE & BRG.	1
5	90620559	FIELD & CASE	1
6	90620543	TRANSMISSION ASSY.	1
7	90620557	ARMATURE & BEARING	1
8	90603478-01	TRIGGER LOCK BUTTON	1
9	90604113	TRIGGER BAR SPRING	1
10	90603477-01	TRIGGER	1
11	90604059	BLADE GUARD	1
12	90604058	AUX. HANDLE	1
13	90604277	GEARCASE COVER ASSY.	1
14	098120-16	SCREW	4
15	330045-06	SCREW	4
16	608175-00	SCREW	2
17	330019-13	SCREW,PLASTITE	18
18	330019-15	SCREW,PLASTITE	1
19	5119820-00	PIN	2
20	657339-00	FLAT WASHER	2
22	90603148	BLADE ASSEMBLY	1
23	90606956	SWITCH & MODULE	1
24	90609420	BLADE COVER	1
25	90607673	FELT SEAL	1
26	90604153	BEARING PLATE	1
27	90603147	CONNECTING ROD	2
28	90616501	SCREW & WASHER	2

Parts List for DCHT860M1 Type 1

Item Number	Part Number	Description	Qty Required
29	90605114	SWITCH SUPPORT	1
31	90605769	ASSEMBLY- EJECTOR	1
32	90606556	LATCH BUTTON	1
33	330045-07	SCREW M4X20 T20	4
34	330016-15	FLAT WASHER	4
35	90606555	BATTERY LATCH	1
36	90606558	LATCH SPRING	2
37	90607453	SPRING SUPPORT	1
38	90608666	BRUSH W/LEAD	2
39	90577405	BRUSH SPRING	2
120	90608524	RATING LABEL	1
121	90608525	WARNING LABEL	1
122	90617167	WARNING LABEL	1
123	90617168	WARN LABEL	1
866	DCB404	BATTERY PACK	1
871	DCB114	CHARGER	1