



Parts List for DCT411S1 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|------------------|--------------|
| 1 | N130093 | LABEL SET | 1 |
| 2 | N118585 | IDENT. LABEL | 1 |
| 3 | N081558 | HANDLE ASSEMBLY | 1 |
| 4 | N127850 | MONITOR ASSEMBLY | 1 |
| 5 | N080683 | CABLE CAMERA | 1 |
| 8 | 330015-00 | NUT | 2 |
| 8 | N068674 | BELT HOOK | 1 |
| 856 | N115242 | ACCY PACK | 1 |
| 861 | N068612 | KIT BOX | 1 |
| 866 | DCB120 | BATTERY PACK | 1 |
| 871 | DCB100 | CHARGER | 1 |