



Parts List for DW614-B2 Type 4

Item Number	Part Number	Description	Qty Required
1	868627-01	ARMATURE	1
2	868628-00	FIELD	1
3	760952-00	SWITCH	1
4	247533-11	BRUSH & HOLDER	2
7	943047-01	CASE,FIELD	1
8	581285-01	SUPPRESSOR	1
9	868520-00	CORD PROTECTOR	1
10	330003-05	BEARING,BALL	1
10	330003-05	BEARING,BALL	1
11	868069-00	CLAMP,BR.HOLDER	2
12	249278-01	SCALE	1
13	576118-00	CORD CLAMP	1
14	868521-00	GUIDE	1
16	868522-00	BAFFLE, FAN	1
17	943054-00	FAN	1
18	868047-00	PLATE	1
19	868768-16	BALL BEARING	1
20	868523-01	DEPTH STOP	1
21	249108-00	SPACER	2
22	249118-00	HANDLE	2
23	868524-00	PIN	1
24	248954-00	HOUSING,LOWER	1
25	868052-00	NUT	1
28	720664-00	BALL	1
29	868082-00	SPRING	1
30	577860-00	BASE ASSY.	1
31	949728-03	CIRCLIP	1

Parts List for DW614-B2 Type 4

Item Number	Part Number	Description	Qty Required
32	949877-02	CAPACITOR	1
33	868530-04	LEAD, YELLOW	1
34	248953-00	SPRING	1
35	868566-00	ROD	1
38	943042-00	BASE	1
39	249014-01	BUSH	1
40	720674-01	TURRET	1
41	868092-00	WASHER	1
42	860658-01	WASHER,SPRING	1
43	249432-00	SCREW	1
44	860083-02	NUT	3
45	942931-02	SCREW	1
46	942931-01	SCREW	1
47	868109-00	SCREW	1
52	249412-22	SCREW	2
53	860205-04	SCREW	11
54	249416-10	SCREW	4
55	949896-12	SCREW	10
56	930752-00	SCREW	2
57	868530-02	LEAD,BLUE	1
58	868530-07	LEAD,BLUE	1
64	868148-00	SPANNER	1
66	249413-03	SCREW	4
67	941580-00	WRENCH	1
69	943051-00	SPRING	1
70	943114-00	LOCK,SPINDLE	1
71	943057-00	COVER	1

Parts List for DW614-B2 Type 4

Item Number	Part Number	Description	Qty Required
82	945304-01	DUST EXTRACTION	1
83	249232-10	NUT	2
84	868080-00	ROD	2
85	326573-01	SCREW,WING	5
86	249090-00	GUIDE	2
87	000000-00	No Longer Available	1