





Parts List for DW788LS Type 1

Item Number	Part Number	Description	Qty Required
1	286380-00	HOUSING,LEFT	1
2	5140061-88	HOUSING SET	1
3	286263-00	BASE,FRONT	1
4	286264-00	TRUNNION	1
5	286265-00	TABLE	1
6	286266-00	ARM,RIGHT BOTTM	1
7	286267-00	ARM,TOP	1
8	286268-00	ROCKER ASY,VERT	1
9	286269-00	LINK,DRIVE	2
10	286270-00	ROCKER ASY,FRNT	2
11	286276-00	STRUT ASSY	2
12	286277-00	MOUNT,ROCKR.TOP	1
13	286278-00	MOUNT,ROCKR.BTM	1
14	286279-00	MOUNT & O-RING	1
16	286281-00	COUNTERWEIGHT	1
19	286282-00	ROD,PIVOT	1
23	286283-00	WEDGE,TENSION	1
24	286284-00	ROD,DRAW	1
25	286285-00	BEARING,SLEEVE	1
26	286286-00	CAM,TENSION	1
27	286287-00	SCREW,M5	1
28	286288-00	LOCKNUT,M5	1
30	286289-00	BELLOWS	1
31	286290-00	CAP,AIR PUMP	1
32	330045-05	LOCK SCREW	2
33	286291-00	BAR	1
34	286292-00	FOOT	1

Parts List for DW788LS Type 1

Item Number	Part Number	Description	Qty Required
36	5140099-98	BLADE CHUCK	2
38	286294-00	SLEEVE,SHORT	12
39	286295-00	SLEEVE,LONG	2
40	286296-00	SCREW,M6	8
41	286297-00	SCREW,M4	8
42	286298-00	SCREW,M8	2
43	429711-00	M6X15 SCREW	6
44	286300-00	SCREW,M5	13
45	286301-00	SCREW,SET	2
46	145439-04	KNOB	1
47	286303-00	KNOB ASY,CLAMP	2
52	286304-00	SCREW,M8	1
55	286305-00	SCREW,M6	2
57	330021-01	NUT,STOP	9
58	330021-00	NUT,ELASTIC STP	12
60	286306-00	MOTOR ASSY	1
61	5140101-32	PC BOARD ASSY	1
62	36485-98	CORD/15FT./18-3	1
64	5140092-86	SWITCH	1
67	286310-00	KNOB,CONTROL	1
68	286311-00	NOZZLE,AIR	1
69	286312-00	HARNESS,WIRE	1
71	286313-00	HOUSING	1
74	326573-01	SCREW,WING	1
75	286316-00	SCREW,M6	1
76	286317-00	INDICATOR,ZERO	1
78	098012-11	MACH SCREW	4

Parts List for DW788LS Type 1

Item Number	Part Number	Description	Qty Required
80	286319-00	LID	1
81	286320-00	ARM,LEFT BOTTOM	1
82	286280-00	CON ROD ASSY	1
83	286322-00	SCREW,M4	1
84	286323-00	SCREW,M4	2
85	286324-00	HOLDER & CAP	1
86	286325-00	RELIEF,STRAIN	1
87	286326-00	WASHER,WAVY	1
88	286327-00	INSERT,RAMP	1
89	286328-00	GUARD,LOWER	1
91	286330-00	SPACER	1
92	286331-00	NUT,M8 (LH)	1
93	286332-00	NUT	1
96	99289-07	SCREW	4
97	286333-00	SCREW,SET	1
100	488807-00	FLAT WASHER	1
101	098000-11	WRENCH	1
102	286334-00	WASHER,EX.TH	1
103	582829-00	WASHER	1
104	286336-00	RING,O	1
105	286337-00	BOLT,M6	1
106	286338-00	CLAMP	1
107	286339-00	LABEL,WARNING	1
108	286340-00	NAMEPLATE	1
109	286036-00	PLATE,DEWALT	1
110	429539-00	LABEL,WARNING	1
111	286343-00	SCREW,M4	1

Parts List for DW788LS Type 1

Item Number	Part Number	Description	Qty Required
112	286344-00	FUSE,3A	1
113	94593-03	TERMINAL	2
114	450213-00	TERMINAL,FEMALE	6
115	680131-03	TERMINAL,FEMALE	2
116	286324-00	HOLDER & CAP	1
117	286346-00	BRUSH	2
118	5140009-98	BRUSH CAP	2
119	286427-00	WASHER,M4 BELLE	8
120	286428-00	WASHER,M5 BELLE	2
121	286429-00	WASHER	1
123	286431-00	WASHER,THRUST	4
124	286432-00	WASHER	2
125	286455-00	PAD	1
856	000000-00	No Longer Available	1
856	DW7881	SCROLL SAW LAMP	1
856	DW7880	SCROLL SAW STAND	1