



Parts List for DWE560-B2 Type 1

Item Number	Part Number	Description	Qty Required
1	N178802	FIELD ASSY.	1
2	N178804	ARMATURE ASSY.	1
3	330003-60	BEARING	1
4	605040-59	BEARING	1
5	N083602	BAFFLE	1
6	330019-19	SCREW	2
7	N195192	FIELD CASE	1
8	N086362	FRONT HANDLE	1
9	N172018	BRUSH HOLDER	2
10	N024448	BRUSH CAP	2
11	N092201	SWITCH	1
12	330045-20	SCREW,M5X45	3
13	330065-31	SCREW	6
14	N083601	END CAP	1
15	330065-27	SCREW	4
16	320078-00	BLOCK,TERMINAL	1
17	821070	CORD CLAMP	1
18	N017542	SCREW	2
19	N105376	PAD PROTECTOR	1
20	330019-02	SCREW,PLASTITE	1
21	N083610	SPRING	1
22	N102412	HOLDER PROTECTOR	1
23	N083609	CORD PROTECTOR	1
24	N114585	CORD SET	1
25	N083584	SHAFT LOCK	1
26	N130051	SPRING	1
27	N177902	GEAR CASE ASSY.	1

Parts List for DWE560-B2 Type 1

Item Number	Part Number	Description	Qty Required
28	381066-00	BUMPER	1
29	N086355	SCREW	1
30	N134472	O-RING	1
31	N183366	SPINDLE ASSY.	1
32	385915-04	SCREW	3
33	N083599	TORSION SPRING	1
34	N083598	LOWER GUARD	1
35	N086628	GUARD LEVER	1
36	098094-13	SCREW	1
37	N152544	RETAIN-EXTERNAL RING	1
38	N112958	INNER FLANGE	1
39	N191811	RUBBER SEAL	1
40	145343-01	CLAMP, OUTER BLD	1
41	145344-00	SCREW, SPECIAL	1
42	152211-00	RING, RETAINING	1
43	N112955	LEVER	1
44	N111116	ACORN NUT	1
45	N143277	CARRIAGE BOLT	1
46	389562-00	PIN	1
47	N136649	SHOE ASSY.	1
48	N116044	BEVEL KNOB	1
49	N038133	BOLT	1
50	N094309	SET SCREW	1
51	N116069	KNOB	1
52	N083612	RIP FENCE	1
53	N170858	SPRING	1
54	N141344	NAME PLATE	1

Parts List for DWE560-B2 Type 1

Item Number	Part Number	Description	Qty Required
55	N106861	CAPACITOR	1
56	N100358	O-RING	1
57	N195215	DUST PORT ASSY.	1
58	N035355	WRENCH	1
59	N179042	BRUSH SET (2)	1
800	583534-00	GREASE	1
861	N044228	KITBOX	1
862	605265-00	SPRING CLIP	1