


Parts Breakdown for DSLT-770 Double Scissor Lift Table



Parts List for DSLT-770 Double Scissor Lift Table

| Index No. | Part No. | Description | Size | Qty |
|-----------|---------------|-------------------------------|--------------------|-----|
| 1..... | DSL770-01 | Table | | 1 |
| 2..... | DSL770-06 | Link Shaft..... | | 2 |
| 3..... | DLS770-02 | Link Assembly | | 1 |
| 4..... | DSL770-03 | C-Ring | Ø 16 m..... | 8 |
| 5..... | DSL770-04 | Roller Guide | | 2 |
| 6..... | DSL770H-06 | Nut | M12..... | 4 |
| 7..... | DSL770H-07 | Spring Washer..... | Ø 12 mm..... | 4 |
| 8..... | SLT660FH-26 | Washer | Ø 12 mm..... | 4 |
| 9..... | DSL770H-09 | Shaft..... | | 2 |
| 10..... | DSL770-12 | Link Shaft..... | | 2 |
| 11..... | DSL770H-11 | Roller Guide | | 2 |
| 12..... | DSL770H-12 | Handle | | 1 |
| 13..... | SLT660FH-09 | Release Lever | | 1 |
| 14..... | SLT660FH-10 | Cable | | 1 |
| 15..... | SLT660FH-11 | Spring Pin | Ø 6 x 28 mm..... | 1 |
| 16..... | SLT660FH-26 | Washer | Ø 12 mm..... | 2 |
| 17..... | DSL770H-07 | Spring Washer..... | Ø 12 mm..... | 2 |
| 18..... | DSL770H-18 | Hex Cap Screw | M12 x 25..... | 2 |
| 19..... | DSL770H-19 | Frame | | 1 |
| 20..... | SLT660FH-25 | Hex Cap Screw | M12 x 95..... | 4 |
| 21..... | SLT660FH-26 | Washer | Ø 12 mm..... | 8 |
| 22..... | SLT660FH-27 | Bearing | 6203ZZ..... | 8 |
| 23..... | SLT660FH-28 | Wheel | 5"..... | 4 |
| 24..... | SLT660FH-29 | Bushing | | 4 |
| 25..... | SLT660FH-30 | Lock Nut | M12 | 4 |
| 26..... | TS-1490031 | Hex Cap Screw | M8 x 20..... | 8 |
| 27..... | TS-1550061 | Flat Washer..... | Ø 8 mm..... | 8 |
| 28..... | SLT660FH-33 | Swivel Wheel Holder | | 2 |
| 29..... | TS-1550061 | Flat Washer..... | Ø 8 mm..... | 8 |
| 30..... | TS-1541031 | Lock Nut | M8..... | 8 |
| 31..... | SLT660FH-36 | Brake Plate | | 2 |
| 32..... | SLT660FH-37 | Stop Support | | 2 |
| 33..... | SLT660FH-38 | C-Ring | Ø 18 mm..... | 2 |
| 34..... | SLT660FH-39 | Shaft..... | | 1 |
| 35..... | DSL770H-35 | Hydraulic Pump Assembly | | 1 |
| [1]..... | SLT660F-36-1 | Oil Seal* | DHS30..... | 1 |
| [2]..... | DSL770-35-2 | Top Nut | | 1 |
| [3]..... | SLT660F-36-3 | O-Ring* | Ø 36x3.5 mm..... | 1 |
| [4]..... | DSL770H-35-4 | Lift Piston | | 1 |
| [5]..... | DSL770H-35-5 | O-Ring* | Ø 21x2.4 mm..... | 1 |
| [6]..... | DSL770H-35-6 | Piston Bushing | | 1 |
| [7]..... | DSL770H-35-7 | U-Packing* | D50 | 1 |
| [8]..... | DSL770H-35-8 | C-Ring | Ø 22 mm..... | 1 |
| [9]..... | SLT660F-36-8 | Air Breather | | 1 |
| [10]..... | SLT660F-36-9 | O-Ring* | Ø 11x1.9 mm..... | 1 |
| [11]..... | SLT660F-36-16 | Valve Plug | M16x2..... | 1 |
| [12]..... | SB-12MM | Steel Ball | Ø 12mm..... | 1 |
| [13]..... | SLT660F-36-18 | Spring | | 1 |
| [14]..... | SLT660F-36-19 | Steel Ball | Ø 9.525 mm | 1 |
| [15]..... | SLT660F-36-20 | Steel Ball | Ø 6.35 mm | 1 |
| [16]..... | SLT660F-36-10 | Relief Plug | | 1 |
| [17]..... | SLT660F-36-21 | Relief Adjusting Screw | | 1 |
| [18]..... | SLT660F-36-22 | O-Ring* | Ø 11 x 1.9 mm..... | 2 |
| [19]..... | SLT660F-36-23 | Spring | | 1 |

| Index No. | Part No. | Description | Size | Qty |
|------------------|-----------------|---|---------------|------------|
| [20] | SLT660F-36-14 | Steel Ball Support | | 1 |
| [21] | SB-5MM | Steel Ball | Ø 5 mm | 1 |
| [22] | SLT660F-36-21 | Screw | M10 x 1 | 1 |
| [23] | SLT660F-36-9 | O-Ring* | Ø 11 x 1.9 mm | 1 |
| [24] | SLT660F-36-23 | Spring | | 1 |
| [25] | SLT660FH-40-24 | Steel Ball Support | | 1 |
| [26] | SB-5MM | Steel Ball | Ø 5 mm | 1 |
| [27] | SLT660F-36-25 | Spring | | 1 |
| [28] | SLT660F-36-26 | O-Ring* | Ø 10 x 1.9 mm | 1 |
| [29] | SLT660F-36-27 | Adjusting Shaft | | 1 |
| [30] | SLT660FH-40-29 | Inner Washer* | | 1 |
| [31] | SLT660F-36-29 | Pump Cylinder | | 1 |
| [32] | SLT660F-36-32 | Screw | | 1 |
| [33] | SLT660F-36-33 | Valve Plug | | 1 |
| [34] | SLT660F-36-34 | Spring | | 1 |
| [35] | SLT660F-36-30 | Screw | | 1 |
| [36] | SB-5MM | Steel Ball | Ø 5 mm | 1 |
| [37] | SLT660F-36-36 | Pump Piston | | 1 |
| [38] | SLT660F-36-35 | Oil Seal* | UHS23.5 | 1 |
| [39] | SLT660F-36-37 | Oil Seal* | UHS18 | 1 |
| [40] | SLT660F-36-38 | U-Packing* | DHS18 | 1 |
| [41] | DSL770FH-35-41 | Outer Washer* | | 2 |
| [42] | DSL770FH-35-42 | Inside Cylinder Tube | | 1 |
| [43] | DSL770FH-35-43 | Inside Washer* | | 1 |
| [44] | SLT660FH-40-43 | O-Ring* | Ø 12 x 1.9mm | 1 |
| [45] | SLT660FH-40-44 | Special Lowering Valve | | 1 |
| [46] | SLT660FH-40-45 | Filter | | 1 |
| [47] | DSL770FH-35-47 | Outer Cylinder Tube | | 1 |
| [48] | DSL770FH-35-48 | Pump Body | | 1 |
| [49] | DSL770H-35-49 | Pump Piston Assembly (index # [32] thru [38]) | | 1 |
| 36 | SLT660FH-41 | Adjusting Screw | | 1 |
| 37 | SLT660F-70 | Hex Nut | Ø 8 mm | 1 |
| 38 | SLC660F-38 | C-Ring | Ø 20 mm | 2 |
| 39 | SLT660FH-44 | Bushing | | 1 |
| 40 | SLC660F-39 | Shaft | | 1 |
| 41 | SLT660FH-46 | Bushing | | 1 |
| 42 | SLT660F-67 | Fixed Seat | | 1 |
| 43 | SLT660F-68 | Spring Washer | Ø 5 mm | 2 |
| 44 | SLT660F-74 | Screw | M5 x 14 | 2 |
| 45 | SLT660F-69 | Spring Pin | Ø 6 x 22 mm | 1 |
| 46 | TS-2311081 | Hex Nut | M8 | 1 |
| 47 | SLT660F-73 | Fixed Board | | 1 |
| 48 | SLT660F-70 | Hex Nut | M8 | 1 |
| 49 | SLT660F-71 | Socket Set Screw | M8 x 30 | 1 |
| 50 | SLT660F-72 | Hex Cap Screw | M8 x 25 | 1 |
| 51 | SLC660F-40 | Spring | | 1 |
| 52 | SLC660F-41 | Spring Cover | | 1 |
| 53 | SLT660FH-58 | Pin | | 1 |
| 54 | SLT660FH-59 | Pin | | 1 |
| 55 | SLC660F-42 | Slide Plate | | 1 |
| 56 | SLC660F-56 | Bushing | | 1 |
| 57 | TS-1550071 | Washer | Ø 10 mm | 2 |
| 58 | SLT660FH-63 | Lock Pin | Ø 3 x 30 mm | 2 |
| 59 | SLC660F-45 | Lever | | 1 |
| 60 | SLC660F-45A | Rubber Bumper | | 1 |
| 61 | TS-2361081 | Spring Washer | Ø 8 mm | 1 |
| 62 | TS-1490051 | Hex Cap Screw | M8 x 30 | 1 |

| Index No. | Part No. | Description | Size | Qty |
|------------------|-------------------|---|----------------|------------|
| 63 | SLC660F-46 | Foot Lever | | 1 |
| 64 | SLC660F-47 | Foot Lever Pad | | 1 |
| 65 | SLT660FH-70 | Hex Cap Screw | M10 x 30 | 1 |
| 66 | DSL770H-66 | Safety Bar | | 1 |
| 67 | SLT660FH-72 | Hex Nut | M10 | 1 |
| 68 | SLT660FH-73 | Hex Cap Screw | M6 x 10 | 1 |
| 69 | SLT660FH-74 | Spring Washer | Ø 6 mm | 1 |
| 70 | SLT660FH-75 | Spring Clip | | 1 |
| 71 | DSL770H-71 | Handle Assembly (index # 12 thru 15) | | 1 |
| 72 | SLT660FH-77 | Front Wheel Assembly (index # 20 thru 25) | | 1 |
| 73 | SLT660FH-78 | Swivel Wheel Assembly (index # 20-25, 28, 31, 32) | | 1 |
| | DSL770-RK | Repair Kit | | 1 |

Index numbers with brackets [] are part of the Hydraulic Pump Assembly, DSLT770H-35.

Parts included in the Repair Kit are indicated by an asterisk *.