


JLP-75 thru JLP-600 – Parts Breakdown



## JLP-75 – Parts List

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
1	JLP75-1	Gear Case Assembly		1
		..... Gear Case		1
		..... Bushing		2
		..... Cover Plate		1
		..... Rivet	2x6	2
2	JLP75-2	Spur Gear Assembly		2
		..... Spur Gear		2
		..... Pinion Gear		2
3	JLP75-3	Drive Shaft		1
4	JLP75-4	Load Gear		1
5	JLP75-5	Gear Side Plate Assembly		1
		..... Gear Side Plate		1
		..... Stay Bolt		3
		..... Bushing		2
		..... Race "A"		1
6	JLP75-6	Load Sheave		1
8	JLP75-8	Guide Block		1
9	JLP75-9	Guide Roller		1
10	JLP75-10	Stripper		1
11	JLP75-11	Roller Kit (34 rollers)	3x5	1
12	JLP75-12	Bearing Race		1
13	JLP75-13	Pawl Spring (1/2, 3/4T)		2
14	JLP75-14	Pawl		2
15	JLP75-15	Snap Ring (1/2, 3/4T)	8	2
16	JLP75-16	Lever Side Plate Assembly		1
		..... Lever Side Plate		1
		..... Race "B"		1
		..... Pawl Pin		2
17	JLP75-17	Disc Hub		1
18	JLP75-18	Spring (1/2, 3/4, 1-1/2T)		1
19	JLP75-19	Friction Disc		2
20	JLP75-20	Ratchet Disc		1
21	JLP75-21	Feed Gear		1
21A	JTP75-21	Feed Gear		1
22	JLP75-22	Brake Cover Assembly		1
		..... Brake Cover		1
		..... Handle Case		1
		..... Nut		2
		..... Bushing		1
23	JLP75-23	Change Over Gear		1
23A	JTP75-23	Change Over Gear		1
24	JLP75-24	Lever Handle Assembly (1/2, 3/4T)		1
		..... Lever Handle		1
		..... Selector Lever		1
		..... Change Over Shaft		1
		..... Cover		1
		..... Rivet	3x12	1
		..... Bolt		2
		..... Spring Seat		1
		..... Bushing		1
		..... Rubber Grip		1
24A	JLP75-24A	Rubber Grip		1
25	JLP75-25	Change Over Pawl (1/2, 3/4T)		1
26	JLP75-26	Spring Shaft (1/2, 3/4T)		1
27	JLP75-27	Spring (1/2, 3/4T)		1

## JLP-75 – Parts List

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty</b>
28	JLP75-28	Hand Wheel (1/2, 3/4T)		1
28A	JTP75-28	Hand Wheel (1/2, 3/4T)		1
29	JLP75-29	Name Plate		1
29A	JTP75-29	Name Plate		1
30	JLP75-30	Chain Stop (1/2, 3/4T)		1
31	JLP75-31	Hex Nut (1/2, 3/4T)	M8	6
32	JLP75-32	Lock Washer (1/2, 3/4T)	M8	6
32A	JLP75-32A	Flat Washer	M8	6
33	JLP75-33	Hex Nut (1/2, 3/4T)	M6	2
34	JLP75-34	Lock Washer (1/2, 3/4T)	M6	2
34A	JLP75-34A	Flat Washer (1/2, 3/4T)	M6	4
35	JLP75-35	Castle Nut (1/2, 3/4T)	M10	1
36	JLP75-36	Split Pin (1/2, 3/4T)	2.5x20	1
37	JLP75-37	Rivet (1/2-6T)	2.5x6	6
40	JLP75-40	Top Hook Assembly		1
		Top Hook		1
		Safety Latch		1
		Double Spring		1
		Rivet	3x16	1
		Top Hook Block		2
		Rivet	5x20	2
41	JLP75-41	Top Hook Shaft		1
43	JLP75-43	Bottom Hook Assembly		1
		Bottom Hook		1
		Safety Latch		1
		Double Spring		1
		Rivet	3x16	1
		Bottom Hook Block		2
		Rivet	5x20	4
43A	JLP75-43A	Shaft		1
43C	JLP75-43C	Nut	M6	1
43D	JLP75-43D	Pin	1.6x14	1
50	JLP75-50	Screw (1/2, 3/4T)	M6x12	2
58	JLP75-58	Snap Ring	28	1
80	JTP75-80	Overload Limiting Plate A		1
81	JTP75-81	Overload Limiting Plate B		1
82	JTP75-82	Pressure Plate		1
83	JTP75-83	Dish Spring		1
84	JTP75-84	Adjusting Nut		1
100	JLP75-100	Safety Latch Kit		1
		Safety Latch		1
		Double Spring		1
		Rivet	3x16	1
		Chain	6mm	1
	187722			

**Note:** Top and bottom hooks are sold as an assembly only.