


JLH Series Lever Hoists (JLH-80/100/160/250/320/630/900)



Parts List: JLH-100 (1 Ton)

Parts listed under each assembly are parts that make up that assembly.

Index No.	Part No.	Description	Size	Qty
1.....	JLH80-1	Gear Case Assembly (0.8, 1 Ton).....		1
Gear Case.....		1
Bushing.....		3
Cover Plate		1
2	JLH80-2	Spur Gear Assembly (0.8, 1 Ton).....		2
Spur Gear.....		2
Pinion Gear		2
3.....	JLH80-3	Driving Shaft (0.8, 1 Ton).....		1
JLH80-3-1.....Driving Shaft (0.8, 1 Ton) (<i>models from 02-01-2009 and forward</i>)		1
4.....	JLH80-4	Load Gear (0.8, 1 Ton)		1
5.....	JLH80-5	Gear Side Plate Assembly (0.8, 1 Ton).....		1
Gear Side Plate.....		1
Bushing.....		2
6.....	JLH80-6	Caged Roller Bearings (0.8, 1 Ton).....	Ø35xØ25x10mm	2
7.....	JLH80-7	Load Sheave (0.8, 1 Ton)		1
8.....	JLH80-8	Guide Roller (0.8, 1 Ton)		2
9.....	JLH80-9	Stripper (0.8, 1 Ton)		1
10.....	JLH80-10	Lever Side Plate Assembly (0.8, 1 Ton).....		1
Lever Side Plate.....		1
Stay Bolt.....		4
Pawl Pin.....		2
11.....	JLH80-11	Pawl Spring (0.8, 1 Ton)		2
12.....	JLH160-12	Pawl (0.8, 1, 1.6 Ton)		2
13.....	JLH160-13	Snap Ring (0.8, 1, 1.6, 2.5 Ton).....	Ø 9mm	2
14.....	JLH160-14	Disc Hub (0.8, 1, 1.6, 2.5 Ton)		1
15.....	JLH160-15	Ratchet Disc (0.8, 1, 1.6, 2.5 Ton)		1
16.....	JLH80-16	Brake Cover Assemby (0.8, 1 Ton)		1
Brake Cover		1
Handle Case		1
Bushing.....		1
Thread Housing.....		1
17.....	JLH160-17	Hex Nut (0.8, 1, 1.6, 2.5 Ton).....	M6	2
17A	JLH160-17A.....	Lock Washer (0.8, 1, 1.6, 2.5 Ton).....	6mm	2
18	JLH80-18	Lock Washer (0.8 to 9 Ton)	8mm	8
19.....	JLH80-19	Acorn Nut (0.8 to 9 Ton)	M8	8
20.....	JLH160-20	Change Over Gear (0.8, 1, 1.6, 2.5 Ton).....		1
JLH160-20-1.....Change Over Gear (0.8, 1, 1.6, 2.5 Ton).....		1
(models from 02-01-2009 and forward).....		
20L.....	JLH100-20L	Overload Limiter Assembly (For JLH-100WO-10 only)		1
JLH100-20L-1.....Overload Limiter Assembly (For JLH-100WO-10 only)		1
(models from 02-01-2009 and forward).....		
Overload Limiting Plate.....		1
Change Over Gear		1
Pressure Plate.....		1
Dish Spring.....		1
Adjusting Nut.....	M22x1.25-7H	1
21.....	JLH160-21	Change Over Pawl (0.8, 1, 1.6, 2.5 Ton)		1
22.....	JLH160-22	Spring Shaft (0.8, 1, 1.6, 2.5 Ton).....		1
23.....	JLH160-23	Spring (0.8, 1, 1.6, 2.5 Ton).....		1
24.....	JLH80-24	Lever Handle Assembly (0.8, 1 Ton)		1
Lever Handle		1
Selector Lever		1
Change Over Shaft		1
Bolt		2
Spring Seat		1
Bushing		1

24A	JLH80-24A	Rubber Grip (0.8, 1 Ton)		1
25	JLH160-25	Hex Cap Screw (0.8, 1, 1.6 Ton)	M6 x 12	1
25A	JLH160-25A	Lock Washer (0.8, 1, 1.6 Ton)	6mm	1
26	JLH160-26	Cam (0.8, 1, 1.6, 2.5 Ton)		1
	JLH160-26-1	Cam (0.8, 1, 1.6, 2.5 Ton) (<i>models from 05-01-2008 to 01-31-2009</i>)		1
	JLH160-26-2	Cam (0.8, 1, 1.6, 2.5 Ton) (<i>models from 02-01-2009 and forward</i>)		1
27	JLH160-27	Twisting Spring I (0.8, 1, 1.6, 2.5 Ton)		1
28	JLH160-28	Hand Wheel (0.8, 1, 1.6, 2.5 Ton)		1
	JLH160-28-1	Hand Wheel (0.8, 1, 1.6, 2.5 Ton) (<i>models from 02-01-2009 and forward</i>)		1
29	JLH160-29	Twisting Spring II (0.8, 1, 1.6, 2.5 Ton)		1
30	JLH160-30	Twisting Spring Housing (0.8, 1, 1.6, 2.5 Ton)		1
31	JLH160-31	Castle Nut (0.8, 1, 1.6, 2.5 Ton)	M8	1
32	JLH80-32	Split Pin (0.8 to 9 Ton)	2 x 18mm	1
33	JLH80-33	Rivet (0.8 to 9 Ton)	3 x 6mm	4
34	JLH100-34	Name Plate		1
35	JLH160-35	Lock Nut (0.8, 1, 1.6, 2.5 Ton)	M6	1
36	JLH80-36	Bottom Hook Shaft (0.8, 1 Ton)		1
37	JLH100-37	Safety Latch Kit (1 Ton)		2
		Safety Latch		2
		Double Spring		2
		Socket Cap Screw	M4 x 23	2
		Lock Nut	M4	2
38	JLH100-38	Bottom Hook Holder Assembly (incls. 35 & 36)		1
	JLH100-38-1	Bottom Hook Holder Assembly (incls. 35 & 36) with Thrust Bearing		1
		<i>(models from 09-15-2009 and forward)</i>		
		Bottom Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Cap Screw	M4 x 23	1
		Lock Nut	M4	1
		Bottom Hook Holder		1
		Rivet	6 x 24mm	4
39	JLH80-39	Top Hook Shaft (0.8, 1 Ton)		1
40	JLH100-40	Top Hook Holder Assembly		1
		Top Hook		1
		Safety Latch		1
		Double Spring		1
		Socket Cap Screw	M4 x 23	1
		Lock Nut	M4	1
		Top Hook Holder		1
		Rivet	6 x 24mm	2
41	JLH80-41	Chain Stop (0.8, 1 Ton)		1
42	JLH80-42	Drive Shaft Washer (0.8, 1 Ton)		1
49	JLH80-49	Load Chain (0.8, 1 Ton) – specify length	Ø5.6 x 15.7mm	1
50	JLH160-50	Rubber Grip Fastening (0.8, 1, 1.6, 2.5 Ton)		1
50A	JLH160-50A	Fastening Screw (0.8, 1, 1.6, 2.5 Ton)		1

Note: Top and bottom hooks are sold as an assembly only.

When ordering replacement chain (#49), specify length.