



Operating Instructions and Parts Manual

Web Strap Ratchet Hoists


JWS-Series



JET
427 New Sanford Road
LaVergne, Tennessee 37086
Ph.: 800-274-6848
www.jettools.com

Part No. M-352100
Edition 1 07/2016
Copyright © 2016 JET

11.4.1 JWS-4A Web Strap Hoist – Parts List



11.4.2 JWS-4A Web Strap Hoist – Parts List

Index No.	Part No.	Description	Size	Qty
1	TS-1505011	Hex Socket Head Cap Screw	M10x16	1
2	TS-2361101	Lock Washer	M10	1
3	TS-1550071	Flat Washer	M10	1
4	JWS3A-04	Wing Nut		1
5	JWS3A-05	Handle Assembly		1
6	JWS3A-06	O-Ring		1
7	JWS3A-07	Brake Gear		1
8	JWS4A-08	Center Plate Weldment		1
9	JWS3A-09	Plate A Weldment (large hole)		1
10	JWS3A-10	Plastic Disc (large hole)		1
11	JWS3A-11	Drum		1
12	JWS3A-12	Plate B (small hole)		1
13	JWS3A-13	Pawl		1
14	JWS3A-14	Pawl Screw	M10	1
15	JWS3A-15	Top & Bottom Tube		2
16	JWS2A-16	Clevis Pin with Cotter	M12x29.5	2
17	TS-2210801	Hex Head Cap Screw	M10x80	1
18	JWS3A-18	Web Strap Restraint		1
19	JWS3A-19	Hex Head Cap Screw	M10x6	2
20	TS-1541041	Hex Nylon Lock Nut	M10	4
21	JWS3A-21	Plastic Disc (small hole)		1
22	JWS3A-22	Swivel Shackle Assembly		2
23	JWS3A-23	Pawl Spring		1
24	JWS2A-24	Eye Hook and Latch Assembly		3
25	JWS3A-25	Web Strap		1
26	JWS2A-26	Collar		2
27	JWS3A-27	Hex Head Cap Screw		2
28	JWS3A-28	Clamping Block		1
29	TS-1504011	Hex Socket Head Cap Screw	M8x10	2
30	JWS2A-30	Iron Pin		1
31	F006052	C-Ring, External	30mm	1
33	JWS3A-33	Web Strap Roller		1
34	JWS3A-34	Plastic Cushion		2
35	JWS3A-35	Web Strap Guide Washer		2
	LM000215	Label - Not For Lifting (not shown)	5/8 x 2-5/8 in	1