



11.1.1 Main Body Assembly (2-1/4T Short Chassis Service Jack) – Exploded View



11.1.2 Main Body Assembly (2-1/4T Short Chassis Service Jack) – Parts List

Index No	Part No	Description	Size	Qty
1.....	JSJ21/4XA-01	Front Caster		2
2.....	JSJ3XA-02.....	Washer.....	18mm.....	2
3.....	JSJ3XA-03.....	C-Clip.....	18mm.....	2
4.....	JSJ3S-07	Swivel Caster Assembly		2
5.....	JSJ3S-08.....	Ball Ring.....		2
6.....	JSJ3S-09.....	Steel Ball.....	6.35mm.....	38
7.....	JSJ3S-10.....	Ball Cover.....		2
8.....	JSJ3S-05.....	Lock Washer	16mm.....	2
9.....	JSJ3S-06.....	Hex Nut	M16.....	2
10.....	JSJ21/4XA-10.....	Arm Shaft		1
11.....	JSJ3S-14.....	C-Clip.....	25mm.....	4
12.....	JSJ3S-11.....	Lock Washer	12mm.....	4
13.....	JSJ3S-12.....	Screw	M12x25	2
14.....	JSJ3S-18.....	Hex Nut	M12.....	2
15.....	JSJ21/4XA-15.....	Shaft		2
16.....	JSJ3S-16.....	Washer.....	10mm.....	5
17.....	JSJ21/4XA-17.....	Lock Nut	M10.....	4
18.....	JSJ3S-19.....	Bolt.....	M18.....	1
19.....	JSJ3S-20.....	Lock Washer	18mm.....	2
20.....	JSJ3S-26.....	Torsion Spring		1
21.....	JSJ3S-21.....	Pin.....	2x16mm	1
22.....	JSJ3S-22.....	Washer.....	8mm.....	4
23.....	JSJ3S-27.....	Handle Socket		1
24.....	JSJ3S-24.....	Pin.....		1
25.....	JSJ3S-25.....	Bolt.....		1
26.....	JSJ3S-23.....	Release Valve Gear		1
27.....	JSJ3S-29.....	Screw		1
28.....	JSJ3S-31.....	Bolt.....	M6x35	1
29.....	JSJ3S-32.....	Lower Handle		1
30.....	JSJ3S-34.....	Upper Handle		1
31.....	JSJ3S-33.....	Handle Grip		1
32.....	JSJ21/4XA-32.....	Power Unit Assembly		1
33.....	JSJ3XA-33.....	Gear		1
34.....	JSJ3XA-34.....	Washer.....	8mm.....	1
35.....	JSJ3XA-35.....	Nut	M8.....	1
36.....	JSJ3S-42.....	Return Spring		1
37.....	JSJ3S-41.....	Pin.....	4x50mm	1
38.....	JSJ21/4XA-38.....	Connecting Bar		1
39.....	JSJ3XA-39.....	Screw		1
40.....	JSJ3S-39.....	Grease Fitting	M6.....	1
41.....	JSJ21/4XA-41.....	Lifting Arm Assembly		1
42.....	JSJ21/4XA-42.....	Saddle		1
43.....	JSJ21/4XA-43.....	Bolt		3
44.....	JSJ21/4XA-44.....	Side Plate Assembly		1
45.....	JSJ3S-15.....	Hex Nut	M10.....	1
	JSJ21/4XA-WL.....	I.D./Warning Label (not shown).....		1

11.2.1 Power Unit Assembly (2-1/4T Short Chassis Service Jack) – Exploded View



11.2.2 Power Unit Assembly (2-1/4T Short Chassis Service Jack) – Parts List

Index No	Part No	Description	Size	Qty
.....	JSJ21/4XA-32	Power Unit Assembly (includes 32-1 thru 32-45)		1
32-1	JSJ21/4XA-321	Cylinder Cover		1
32-2	JSJ21/4XA-322	O-Ring *		1
32-3	JSJ21/4XA-323	Seal Ring *		1
32-4	JSJ21/4XA-324	Oil Tank		1
32-5	JSJ21/4X-57	Oil Fill Plug *		1
32-6	JSJ21/4X-54	O-Ring *		1
32-7	JSJ21/4XA-327	Ram		1
32-8	JSJ21/4XA-328	Retainer *		1
32-9	JSJ21/4XA-329	Piston Ring		1
32-10	JSJ21/4XA-3210	Washer *		1
32-11	JSJ21/4XA-3211	O-Ring *		1
32-12	JSJ21/4XA-3212	Pin		1
32-13	JSJ21/4XA-3213	Spring		1
32-14	JSJ21/4XA-3214	Ram Rod		1
32-15	SB-4MM	Steel Ball	4mm	2
32-16	JSJ21/4XA-3216	Spring		1
32-17	JSJ21/4XA-3217	Screw		1
32-18	JSJ21/4XA-3218	O-Ring *		2
32-19	JSJ21/4XA-3219	Retainer *		1
32-20	JSJ21/4XA-3220	Ram		1
32-21	JSJ21/4XA-3221	Seal Ring *		1
32-22	JSJ21/4XA-3222	Cylinder		1
32-23	JSJ21/4X-88	Back Up Ring *	Ø50.2 x ø47 x 1.6	1
32-24	JSJ21/4X-89	O-Ring *	Ø46.5 x ø2.4	1
32-25	JSJ21/4X-100	Filter		2
32-26	JSJ21/4XA-3226	Screw	M8x16	3
32-27	SB-6MM	Steel Ball	6mm	4
32-28	JSJ21/4X-83	O-Ring *	Ø14 x ø2.65	2
32-29	JSJ21/4XA-72	Back Up Ring *	Ø18 x ø14 x 1.5	2
32-30	JSJ21/4X-75	Piston Pump	Ø14	1
32-31	JSJ21/4X-80	Adaptor		1
32-32	JSJ21/4X-81	Spring		1
32-33	JSJ21/4X-69	Adjustment Screw		1
32-34	JSJ21/4XA-3234	O-Ring *		1
32-35	JSJ21/4XA-3235	Screw		1
32-36	JSJ21/4XA-3236	Pin	4x16	1
32-37	JSJ21/4XA-3237	O-Ring *	12.5 x 1.8	1
32-38	JSJ21/4XA-3238	Release Valve Rod		1
32-39	JSJ21/4XA-3239	Pin	4x30 mm	1
32-40	JSJ21/4XA-3240	Steel Ball	5.5mm	2
32-41	SB-8MM	Steel Ball	8mm	2
32-42	JSJ21/4XA-3242	Square Block		2
32-43	SB-10MM	Steel Ball	10mm	2
32-44	JSJ21/4XA-3244	Screw	M12x16x3	2
32-45	JSJ21/4XA-3245	Valve Assembly		1
.....	JSJ21/4XA-SK	Seal Kit (contains items with asterisk *)		