


Breakdown for FS-1636N & FS-1652N Foot Shear



Parts List for the FS-1636N & FS-1652N Foot Shear

Index	Part		Description	Size	Quantity
No.	No.				
1	FS1636N-1		Table		1
	FS1652N-1		Table		1
2	FS1636N-2		Cutter Bar		1
	FS1652N-2		Cutter Bar		1
3	FS1636N-3		Hold Down		1
	FS1652N-3		Hold Down		1
4	FS1636N-4		R.H. Side Panel		1
5	FS1636N-5		L.H. Side Panel		1
6	FS1636N-6		Front Arm Extension		2
7	FS1636N-7		Screw	M12x45	4
8	FS1636N-8		Spring		2
9	FS1636N-9		Stud		2
10	FS1636N-10		Nut	M12	2
11	FS1636N-11		Screw	M12x80	2
12	FS1636N-12		Washer		2
13	FS1636N-13		Finger Guard		1
	FS1652N-13		Finger Guard		1
14	FS1636N-14		Screw	M6x12	4
15	FS1636N-15		Table Scale (L.H.)		1
16	FS1636N-16		Table Scale (R.H.)		1
17	FS1636N-17		Screw	M8x20	4
18	FS1636N-18		Set Screw	M10x45	2
19	FS1636N-19		Screw	M10x50	2
21	FS1636N-21		Bolt	M16x115	4
22	FS1636N-22		Washer	M16	4
23	FS1636N-23		Nut	M16	4
24	FS1636N-24		Upper Knife		1
	FS1652N-24		Upper Knife		1
25	FS1636N-25		Lower Knife		1
	FS1652N-25		Lower Knife		1
26	FS1636N-26		Screw	M10x40	7
27	FS1636N-27		Screw	M10x45	6
28	FS1636N-28		Washer		7
29	FS1636N-29		Washer		6
30	FS1636N-30		Spring Cap		4
31	FS1636N-31		Gib		2
32	FS1636N-32		Screw	M10x55	6
33	FS1636N-33		Nut	M10	6
34	FS1636N-34		Rod		1
	FS1652N-34		Rod		1
35	FS1636N-35		Washer	M16	2
36	FS1636N-36		Nut	M16	2
37	FS1636N-37		Screw	M16x80	1
38	FS1636N-38		Nut	M16	1
39	FS1636N-39		Washer	M16	1
40	FS1636N-40		Hex Socket Cap Screw	M10x30	2
41	FS1636N-41		Spring		2
42	FS1636N-42		Swivel Top		2
43	FS1636N-43		Swivel Bottom		2
44	FS1636N-44		Stud		2
46	FS1636N-46		Nut	M16	2
47	FS1636N-47		Scale (metric)		2
48	FS1636N-48		Scale (inches)		2
49	FS1636N-49		Screw	M4x8	4
50	FS1636N-50		Pin	Ø12x70	2
51	FS1636N-51		Pin	Ø12x45	2

53FS1636N-53.	Brake Pin.....	2
58FS1636N-58.	Rod	2
59FS1636N-59.	Stop.....	1
FS1652N-59.	Stop.....	1
60FS1636N-60.	Extension Bar	2
61FS1636N-61.	Adjusting Block	2
62FS1636N-62.	Adjusting Dial.....	2
63FS1636N-63.	Adjusting Screw.....	2
64FS1636N-64.	Nut	M10..... 2
65FS1636N-65.	Knob.....	4
67FS1636N-67.	Adjusting Bracket.....	2
68FS1636N-68.	Screw	M10x25..... 4
69FS1636N-69.	Bolt.....	M10x25..... 2
70FS1636N-70.	Nut	M10..... 2
71FS1636N-71.	Stop.....	1
FS1652N-71.	Stop.....	1
72FS1636N-72.	"T" Nut.....	3
74FS1636N-74.	Wing Nut.....	M10..... 3
75FS1636N-75.	Bevel Gauge.....	1
76FS1636N-76.	Washer.....	4
77FS1636N-77.	Washer.....	M10..... 5
78FS1636N-78.	Washer.....	2
79FS1636N-79.	Set Screw	M10x50..... 2
80FS1636N-80.	Plate.....	2
81FS1636N-81.	Screw	M12x35..... 4
82FS1636N-82.	Nut	M16..... 4
83FS1636N-83.	Connection Bar.....	Ø16x1081mm
FS1652N-83.	Connection Bar.....	Ø16x1463mm
902FS1636N-902.	Pedal Assembly.....	1
FS1652N-902.	Pedal Assembly.....	1
FS1636N-ID.	ID Label (not shown).....	1
FS1652N-ID.	ID Label (not shown).....	1
FS1636N-W.	Warning Label (not shown).....	1
FS1636N-J.	JET Label (not shown)	1