





## Parts Breakdown

**FS6200**

*Products with multiple versions are listed in subsiding order with the newest version on top not indented*

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	158876-0	LOCATOR, FS4200	1
2	424163-2	DUST SEAL SLEEVE, FS4200	1
3	424235-3	SEAL RING 30, FS4200	1
4	450881-6	LOCK RING, FS4200	1
5	233974-2	RING SPRING 33, FS4200	1
6	232245-4	LEAF SPRING, BFS450Z	1
7	266361-0	TAPPING SCREW 4X30,9553NB	3
8	140306-5	GEAR HOUSING HNA CPL., FS6200	1
9	232050-9	LEAF SPRING, 6820V	1
10	216001-0	STEEL BALL 3.5, 6800DBV	1
11	324983-3	SPINDLE 125N, FS4200	1
16	233126-5	COMP. SPRING 6, 6832	1
17	268229-6	COLLARED PIN 8, FS4200	1
18	227722-9	HELICAL GEAR 38N, FS6200	1
19	216415-3	THRUST NEEDLE GAUGE 821, 6824	1
20	216212-7	WASHER 821, FS4200	1
21	424162-4	SEAL RING, FS4200	1
22	158874-4	GEAR HOUSING COVER CPL., FS4200	1
23	451100-3	RING 8, FS6200	1
24	210007-0	BALL BEARING 608VV, 6825	1
25	240083-0	FAN 52, HR1830F	1
26	515751-7	ARMATURE ASS'Y, FS6200	1
27	681636-0	INSULATION WASHER, 9557PB	1
28	210062-2	BALL BEARING 607ZZ, 9550H	1
29	421868-5	LABYRINTH RUBBER RING,9553NB	1
30	266467-4	TAPPING SCREW 4X50, FS4200	2
31	450880-8	BAFFLE PLATE, FS4200	1
32	633691-8	FIELD, FS4200	1
33	450877-7	MOTOR HOUSING S, FS4200	1
34	162272-6	HOOK, FS4200	1
35	867321-1	NAME PLATE, FS6200	1
36	808576-9	6000RPM INDICATIN LABEL, FS6200	1
37	689111-0	SPACER, HP2050F	2
38	195007-0	CARBON BRUSH SET CB-407, FS4200	1
39	643948-9	BRUSH HOLDER, 6823	1
40	643951-0	BRUSH HOLDER, 6824	1
41	687123-7	STRAIN RELIEF, MT811K	1
42	650614-1	SWITCH, FS4200	1
43	158877-8	HANDLE COVER S CPL., FS4200	1
44	266374-1	TAPPING SCREW 4X25, GA7021	1
45	266374-1	TAPPING SCREW 4X25, GA7021	2
46	631938-4	LIGHT CIRCUIT, FS6200	1
49	265995-6	TAPPING SCREW 4X18, 4323K	2
50	682559-5	CORD GUARD 8, 6824	1
51	664891-9	CORD	1
52	819349-5	CLEAR LABEL, FS4200	1
53	423413-2	RUBBER PLATE, FS4200	1
1,001	784261-7	+ BIT 2-25, FS4200	2
1,002	784801-1	MAGNETIC BIT HOLDER, 6801DBV	1