



## Model XAG26Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
1	266326-2	TAPPING SCREW 4X18	5 PC.
2	183J41-2	MOTOR HOUSING SET	1 SET
	C10 263005-3	RUBBER PIN 6	2 PC.
	D10	INC. 39	
3	455450-8	DUST COVER R	1 PC.
4	632E12-1	SWITCH UNIT	1 PC.
5	650734-1	SWITCH TG73BDS-2	1 PC.
6	234357-9	COMPRESSION SPRING 11	1 PC.
7	142901-7	INDICATOR PANEL COMPLETE	1 PC.
8	142976-6	SWITCH LEVER COMPLETE	1 PC.
9	629203-3	STATOR COMPLETE	1 PC.
10	211021-9	BALL BEARING 607LLB	1 PC.
11	510440-9	ROTOR ASS'Y	1 PC.
	D10	INC. 10	
12	135930-7	GEAR HOUSING COVER ASSEMBLY	1 PC.
	D10	INC. 13	
13	213445-5	O-RING 26	1 PC.
14	210042-8	BALL BEARING 629LLB	1 PC.
15	226950-3	SPIRAL BEVEL GEAR 10	1 PC.
16	252186-8	HEX. NUT M6	1 PC.
17	136209-9	GEAR HOUSING ASS'Y	1 PC.
	D10	INC. 18-21	
18	459967-3	LEVER	1 PC.
19	961017-7	STOP RING E-3	1 PC.
20	232576-1	TORSION SPRING 5	1 PC.
21	256935-5	HEADED PIN 4	1 PC.
22	266361-0	TAPPING SCREW 4X30	4 PC.
23	327460-4	SHAFT	1 PC.
24	961104-2	RETAINING RING S-24	1 PC.
25	226951-1	SPIRAL BEVEL GEAR 37	1 PC.
26	962201-7	RETAINING RING (INT) R-42	1 PC.
27	210208-0	BALL BEARING 6905DDW	1 PC.
28	213622-9	O RING 45	1 PC.
29	136199-6	BEARING BOX ASS'Y	1 PC.
	D10	INC. 28	
30	327322-6	SLEEVE 4	2 PC.
31	232490-1	COMPRESSION SPRING 4	1 PC.
32	347615-5	LEVER	1 PC.
33	911159-7	PAN HEAD SCREW M4X30	2 PC.
34	911138-5	P.H.SCREW M4X20 WITH WR	2 PC.
35	232577-9	SCROW WAVE SPRING 49	1 PC.
36	140T26-1	WHEEL COVER 125L COMPLETE	1 PC.
	C10 813N68-9	CAUTION LABEL	1 PC.
37	327459-9	RING 25	1 PC.
38	127428-8	SPINDLE ASSEMBLY	1 PC.
39	183J41-2	MOTOR HOUSING SET	1 SET
	C10 263005-3	RUBBER PIN 6	2 PC.
	D10	INC. 2	
40	455449-3	DUST COVER L	1 PC.

41	643874-2	TERMINAL	1 PC.
43	857S71-0	XAG26 SERIAL NO. LABEL	1
44	857S70-2	XAG26 NAME PLATE	1
A01	E-00468	GRIDING WHEEL INOX 125 X-LOCK	1 PC.
A02	158237-4	GRIP 36 COMPLETE	1 PC.
A03	140U29-1	WHEEL COVER 125CL COMPLETE	1 PC.
A04	E-00474	THIN CUTTING WHEEL 125 X-LOCK	1 PC.
E01	8008J2-2	CAUTION LABEL	1 PC.