



Model XKH01TJ/Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	286283-8	CAP 38	1 PC.
002	233966-1	RING SPRING 19	1 PC.
003	450275-5	CHUCK COVER	1 PC.
004	234039-3	COMPRESSION SPRING 42	1 PC.
005	257288-5	RING 21	1 PC.
006	216022-2	STEEL BALL 7.0	2 PC.
007	345873-7	GUIDE WASHER	1 PC.
008	233916-6	CONICAL COMP. SPRING 21-29	1 PC.
009	345874-5	STEEL BALL GUIDE	1 PC.
010	450274-7	CHANGE RING	1 PC.
011	231985-1	RING SPRING 43	1 PC.
012	459752-4	SUPPORT RING	1 PC.
013	459748-5	HOUSING COVER	1 PC.
014	213465-9	O RING 31	1 PC.
015	213617-2	O RING 47	1 PC.
016	319988-6	BARREL	1
017	213606-7	O RING 48	1 PC.
018	216002-8	STEEL BALL 4.8	3 PC.
019	331796-5	RING 25	1 PC.
020	922243-3	HEX. SOCKET HEAD BOLT M5X25	4 PC.
021	213008-7	O RING 22.4	1 PC.
022	262142-0	URETHAN RING 26	1 PC.
023	233956-4	RING SPRING 37	1 PC.
024	257296-6	RING 39	1 PC.
025	213142-3	O-RING 35	1 PC.
026	324837-4	TOOL HOLDER	1 PC.
027	213128-7	O RING 12	1 PC.
028	324844-7	IMPACT BOLT	1 PC.
029	424065-2	RUBBER RING 13	1 PC.
030	267363-9	FLAT WASHER 12	1 PC.
031	326814-2	CYLINDER	1 PC.
032	326813-4	RING 29	1 PC.
033	234041-6	COMPRESSION SPRING 32	1 PC.
034	345872-9	CUP WASHER 29	1 PC.
035	268226-2	PIN 6	3 PC.
036	256862-6	ROD 2.5	3 PC.
037	911133-5	PAN HEAD SCREW M4X18	4 PC.
038	419988-7	FILTER CAP	1 PC.
039	213218-6	O RING 16	1 PC.
040	443129-3	FILTER	1 PC.
041	459746-9	CRANK CAP	1 PC.
042	424067-8	SEAL RING	1 PC.
043	324845-5	CRANK SHAFT	1 PC.
044	211232-6	BALL BEARING 6002LLU	1 PC.
045	213219-4	OIL SEAL 15	1 PC.
046	265490-6	HEX. SOCKET HEAD BOLT M4X16	2 PC.
048	318202-7	BEARING BOX	1 PC.
049	213513-4	O RING 39	1 PC.
050	267126-3	FLAT WASHER 22	2 PC.

052	226675-9	HELICAL GEAR 36	1 PC.
053	266041-8	TAPPING SCREW 5X25	4 PC.
054	256087-2	PIN 7	1 PC.
055	324847-1	STRIKER	1 PC.
056	213283-5	O-RING 18	1 PC.
057	213283-5	O-RING 18	1 PC.
058	213262-3	O RING 18	1 PC.
059	450298-3	PISTON	1 PC.
060	450278-9	CONNECTING ROD	1 PC.
061	331797-3	SLEEVE 29	1 PC.
062	232560-6	COMPRESSION SPRING 12	1 PC.
063	158523-3	CRANK HOUSING COMPLETE	1 PC.
C10	213415-4	O RING 28	1 PC.
064	211131-2	BALL BEARING 6001DDW	1 PC.
065	253748-5	FLAT WASHER 12	1 PC.
066	519589-2	ROTOR ASSY	1 PC.
D10		INC. 64,65,67	
067	210022-4	BALL BEARING 626DDW	1 PC.
069	265995-6	TAPPING SCREW 4X18	2 PC.
070	459749-3	BAFFLE PLATE	1 PC.
071	629451-4	STATOR	1 PC.
072	459747-7	MOTOR HOUSING	1 PC.
073	620936-3	LED CIRCUIT	1 PC.
074	232411-3	COMPRESSION SPRING 8	1 PC.
075	265995-6	TAPPING SCREW 4X18	7 PC.
076	183N36-9	HOUSING SET	1 SET
C10	263005-3	RUBBER PIN 6	2 PC.
D10		INC. 88	
077	620796-3	DIAL CIRCUIT	1 PC.
078	140M96-8	MOTOR HOUSING COVER COMPLETE	1 PC.
079	265995-6	TAPPING SCREW 4X18	2 PC.
080	232152-1	LEAF SPRING	1 PC.
081	459751-6	TRIGGER LOCK	1 PC.
082	651399-2	SWITCH C3JW-6B-PA	1 PC.
083	459750-8	SWITCH LEVER	1 PC.
084	232561-4	COMPRESSION SPRING 5	1 PC.
085	620C18-9	CONTROLLER	1 PC.
086	643874-2	TERMINAL	1 PC.
087	265995-6	TAPPING SCREW 4X18	4 PC.
088	183N36-9	HOUSING SET	1 SET
C10	263005-3	RUBBER PIN 6	2 PC.
D10		INC. 76	
089	856L08-2	XKH01 SERIAL NO. LABEL	1
090	911211-1	PAN HEAD SCREW M5X12	2 PC.
091	264002-2	SQUARE NUT M5	2 PC.
093	127344-4	HOOK ASS'Y	1 PC.
094	856L01-6	XKH01 NAME PLATE	1
A01	197213-3	CONNECTOR PLASTIC CASE (TYPE4)	1 PC. (XKH01TJ)
C10	453974-8	LATCH	4 PC. (XKH01TJ)
A02	835D35-4	INNER TRAY	1 (XKH01TJ)
A03	8006H2-6	XKH01TJ PLASTIC CASE LABEL	2 (XKH01TJ)
A04	8006H1-8	XKH01TJ INDICATION LABEL	1 (XKH01TJ)
A05	BL1850B	BATTERY BL1850B SET (197283-2)	2 PC. (XKH01TJ)
A06	450128-8	BATTERY COVER	1 PC. (XKH01TJ)
A07	***DC18RC	DC18RC FAST CHARGER	1 PC. (XKH01TJ)