



## Model XRH06RB/ZB Parts list

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	286037-3	CAP 34	1
002	961057-5	RETAINING RING S-17	1 PC.
003	253377-4	FLAT WASHER 17	1
004	457214-6	CHUCK COVER	1
005	257416-2	RING 21	1
006	216022-2	STEEL BALL 7.0	2 PC.
007	346177-0	GUIDE WASHER	1 PC.
008	232347-6	CONICAL COMP. SPRING 21-29	1
009	921923-8	HEX. BOLT M8X120	1 PC.
010	417911-6	GRIP BASE	1 PC.
011	158057-6	GRIP 36 COMPLETE	1 PC.
C10	931402-8	HEX. NUT M8	1 PC.
012	144218-4	GEAR HOUSING COMPLETE	1
C10	211375-4	BALL BEARING 6805LLB	1 PC.
C20	213788-5	OIL SEAL 25	1 PC.
013	161569-0	CHANGE LEVER COMPLETE	1
014	213278-8	O RING 17	1 PC.
015	161568-2	LOCK BUTTON COMPLETE	1
016	232344-2	COMPRESSION SPRING 3	1
017	326841-9	TOOL HOLDER	1
018	961135-1	RETAINING(EXT) WR-25	2 PC.
020	221483-3	SPUR GEAR 57	1
021	267175-0	FLAT WASHER 24	1 PC.
022	161570-5	CHANGE PLATE COMPLITE	1
023	233194-8	COMPRESSION SPRING 4	2 PC.
024	216019-1	STEEL BALL 3	2 PC.
025	213183-9	X RING 13	1 PC.
026	326843-5	IMPACT BOLT	1
027	326842-7	RING 10	1
028	232343-4	RING SPRING 23	1
029	327007-4	STRIKER	1
030	213128-7	O RING 12	1 PC.
031	319510-9	PISTON CYLINDER	1
032	347101-6	GUIDE PLATE	1
033	326846-9	PISTON JOINT	1
034	232346-8	COMPRESSION SPRING 8	1
035	347102-4	SPRING GUIDE	1
036	326845-1	CLUTCH CAM	1
037	221482-5	SPUR GEAR 8	1
038	219026-3	SWASH BEARING 6	1
039	221481-7	SPIRAL BEVEL GEAR 37	1
040	347100-8	BEARING RETAINER	1
041	266273-7	HEX. SOCKET HEAD BOLT M4X12	1 PC.
042	257415-4	RING 5	1
043	210065-6	BALL BEARING 625ZZ	1 PC.
044	326847-7	RING 5	1
045	265910-0	HEX. SOCKET HEAD BOLT M3X12	2 PC.
046	144219-2	INNER SUPPORT COMPLETE	1
047	213092-2	O-RING 60	1

048	443138-2	FILTER	1 PC.	
049	319508-6	INNER HOUSING	1	
050	265995-6	TAPPING SCREW 4X18	4 PC.	
051	232345-0	CONICAL COMP. SPRING 8-19	1	
052	213008-7	O RING 22.4	1 PC.	
053	619421-1	ROTOR	1	
059	629283-9	STATOR	1	
060	266490-9	TAPPING SCREW PT 2X6	3 PC.	
061	183G09-0	MOTOR CASE SET	1	
	D10	INC. 62		
062	183G09-0	MOTOR CASE SET	1	
	D10	INC. 61		
063	251510-2	H. S. HEAD BOLT M3X12 WITH WRM	4	
064	266130-9	TAPPING SCREW BIND PT 3X16	4 PC.	
065	183H72-9	HOUSING SET	1	
	C10	252126-6	HEX. LOCKING NUT M4-7	2 PC.
	C20	262182-8	RUBBER RING 6	2
	C30	263005-3	RUBBER PIN 6	2 PC.
	C40	812F90-5	CAUTION LABEL	1
	D10	INC. 66		
066	183H72-9	HOUSING SET	1	
	C10	252126-6	HEX. LOCKING NUT M4-7	2 PC.
	C20	262182-8	RUBBER RING 6	2
	C30	263005-3	RUBBER PIN 6	2 PC.
	C40	812F90-5	CAUTION LABEL	1
	D10	INC. 65		
067	266130-9	TAPPING SCREW BIND PT 3X16	9 PC.	
068	853R73-8	XRH06 NAME PLATE	1	
069	853R79-6	XRH06 SERIAL NO. LABEL	1	
070	457210-4	F/R CHANGE LEVER	1	
071	650689-0	SWITCH C3JW-2B	1 PC.	
072	643874-2	TERMINAL	1 PC.	
073	620746-8	CONTROLLER	1	
074	620747-6	LED CIRCUIT	1	
A01	415486-9	DEPTH GAUGE	1 PC.	
A03	832069-4	TOOL BAG	1	(XRH06RB)
A07	450128-8	BATTERY COVER	1 PC.	(XRH06RB)
A08	***DC18RC	DC18RC FAST CHARGER	1 PC.	(XRH06RB)
A09	BL1820B	BATTERY BL1820B SET (197257-3)	2	(XRH06RB)