SERVICE PARTS LIST

BULLETIN NO. 54-06-0583

(21)

(25)

Milwankee. SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS REVISED BULLETIN DATE July 2001 54-06-0582 D.I. 3/8" ANGLE DRILL WIRING INSTRUCTION STARTING SERIAL NO. 611B CATALOG NO. 0375-1 58-01-0373

 $00|_{\overline{0}}$

EXAMPLE: Component Parts (Small #)
Are Included When Ordering




FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
★ 1	18-10-0115	Field	(1)
2	02-04-0300	Ball Bearing	(3)
★ 3	05-74-0025	8-16 x .750 Fillister Hd. Screw	(8)
★ 4	16-10-0645	Armature	(1)
★ 5	05-74-0500	8-16 x .562 Fillister Hd. Screw	(1)
★ 6	31-50-0460	Housing Assembly	(1)
★ 7	32-42-1155	Helical Gear	(1)
★ 8	45-36-1233	Spacer	(1)
★ 9	32-60-2395	Gear & Pinion Assembly	(1)
★ 10	23-66-1377	Switch	(1)
★ 11	06-95-0055	Pan Head Plastite Screw	(2)
12	42-68-0530	Strain Relief Clamp	(1)
13	06-65-0550	Pin	(1)
14	36-17-0070	Bell Crank	(1)
★ 15	44-94-0295	Switch Rod	(1)
★ 16	45-72-0135	Trigger	(1)
★ 17	22-22-1345	Brush & Holder Assembly	(2)
18	44-76-0160	Cord Protector	(1)
19	22-64-0830	Cord Set	(1)
20	02-04-0911	Ball Bearing	(1)
21	02-04-1000	Ball Bearing	(1)
★ 22	38-50-5525	Output Shaft	(1)
23	43-54-0525	Chuck Shroud	(1)
★ 24	48-66-2115	3/8" Chuck	(1)

FIG.	PART NO.	DESCRIPTION OF PART	NO.REQ.
★ 25	05-74-0513	M5 x .8 x 25 L.H. Chuck Screw	(1)
26	02-04-0450	Ball Bearing	(1)
★ 27	12-20-0322	Service Nameplate Kit	(1)
	48-66-3240	Chuck Key	(1)

FIG. LUBRICATION:

Place .80 oz. (22 gm) of Type "Z" Grease, No. 49-08-7655, in the gear cavities of the housing assembly.