



SERVICE PARTS LIST

BULLETIN NO.
55-05-0476

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN	DATE
HEAVY-DUTY S.S. VACUUM CLEANER			Feb. '95
CATALOG NO. 8925-2	STARTING SERIAL NO. 634-1001	WIRING INSTRUCTION	

EXAMPLE:



Component Parts (Small #)
Are Included When Ordering
The Assembly (Large #).

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	22-64-3220	Cord Set	(1)
2	44-76-0230	Cord Protector	(1)
4	23-66-0870	Switch	(1)
5	42-92-0350	Motor Cover Assembly (Includes Fig. Nos. 6 thru 9)	(1)
6	43-62-0510	Handle	(1)
7	43-44-0370	Gasket	(1)
8	42-86-0070	Connector	(1)
9	45-03-0120	Perforated Aluminum Screen	(1)
10	42-04-0450	Motor Adapter	(1)
11	43-44-0470	Motor Top Gasket	(1)
12	23-30-0260	Large By Pass Motor Assembly	(1)
13	22-18-0435	Carbon Brush and Holder (Set)	(1)
14	43-44-0475	Top Motor Gasket	(1)
15	42-92-0270	Container Cover with Screen	(1)
16	49-90-0270	Wire Frame	(1)
17	49-90-0260	Cloth Filter and Gasket	(1)
18	49-90-0150	Swivel End Connector (Incl. Fig. 19)	(1)
19	43-44-0275	Fitted Gasket	(1)
20	42-51-0390	Stainless Steel Dust Container Assy. (Includes Fig. Nos. 21 thru 29)	(1)
21	45-80-0160	Drain Assembly	(1)
22	43-44-0720	Gasket	(1)
23	42-36-1550	Handle Bracket	(2)
24	44-60-0860	Pin and Ring Assembly	(2)
26	42-86-0080	Inlet Connector Assembly	(1)
27	43-44-0370	Gasket	(1)
28	42-68-0291	Holddown Clamp	(3)
29	43-62-0920	Push Handle	(1)
30	49-90-0250	Tool Caddy Bag	(1)
31	49-90-1610	Wet Pick-up Conversion Pan Assembly (Incl. Fig. Nos. 32 thru 35)	(1)
32	42-46-0110	Float Cage Assembly	(1)
33	44-54-0050	Wet Pan Adapter	(1)
34	43-44-0340	Shut Off Gasket	(1)
35	43-44-0330	Gasket	(1)
36	06-85-2000	12 x 1/2 Phillips Type B Pan Hd. Screw	(6)
37	43-08-0190	Dolly Ring Body	(1)
38	45-94-0130	Wheel	(2)
39	06-57-7505	Pal Nut	(2)
40	42-52-0220	Hub Cap	(2)
41	45-94-0140	Swivel Bearing Caster	(2)
42	06-05-0010	Ground Screw Assembly	(2)
43	43-44-0500	Bottom Motor Gasket	(1)
44	49-90-0350	Filter Bags (Package of five) Not Shown	(1)

